


# Installation and Operation Manual – AU/NZ Ortal New Line



ORTAL Heating Systems Ltd.

"The appliance must be installed according to AS/NZS 5601.1 (latest edition)."



# **ORTAL Heating Solutions Ltd.**


#### INSTALLATION & OPERATION MANUAL





#### SAVE THESE INSTRUCTIONS

Make yourself fully aware of all the following instructions and the many features of the Ortal room sealed gas fireplace appliance. DO NOT DISCARD THIS MANUAL!



A barrier designed to reduce the risk of burns from the hot viewing glass is provided with this appliance and shall be installed for the protection of children and other at-risk individuals.

#### **WARNING:**

#### FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly, could result in serious injury, death, or property damage.

Installation and service must be performed by a qualified/authorized installer, service agency, or the gas supplier. INSTALLER: test the operation of the appliance before leaving.

#### **DANGER:** IF YOU SMELL GAS

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Leave the building immediately.
- Immediately call you gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

DO NOT PLACE ARTICLES ON OR AGAINST THIS APPLIANCE.

DO NOT USE OR STORE GASOLINE OR OTHER FLAMMABLE VAPORS AND LIQUIDS IN THE VICINITY OF THIS OR ANY OTHER APPLIANCE.

DO NOT SPRAY AEROSOLS NEAR THIS APPLIANCE WHILE IT IS IN OPERATION.

DO NOT MODIFY THIS APPLIANCE.

# **Testing Standards and Document Information**

The ORTAL decorative room sealed gas appliances have been tested and approved by AGA for use with Natural Gas (NG).

#### Standard references:

- Australian Standard AS/NZS 5601.1 (latest edition Decorative Gas Log and Other Fuel Effect Appliances
- Patent Pending for screen barrier glass bracket: USSN 60/040,074

NOTE: Diagrams and illustrations in this manual are not to scale. All fireplace drawings with correct dimensions are available on our website under Products>Downloads>Diagram.

NOTE: For additional details about installing CC units and/or units with Power Flues, please refer to the specific manuals supplied with the product.

# Table of Contents

Fireplace Safety Information and Warnings
Operating Warnings
Certifications and Codes
Product List: Models and Burners5
Prior to Installation6
Locate the Fireplace6
Fireplace Installation
First Trip to Site: Planning
Second Trip to Site: Installation
Third Trip to Site: Start-up8
Post-Installation9
Initial Burning Period9
Final Inspection Procedure9
Final Checks and User Instruction9
Building Checklist
Framing
Framing Dimensions
Cavity Floor/Platform15
Hearth Extension
Viewing Area Clearances
Clearance around the flue pipe must be maintained
Zero-Clearance Stand-Offs
Heat Release
Heat Release23
Heat Release
Heat Release       23         Air Intake       26         Mounting a TV/Artwork       28
Heat Release       23         Air Intake       26         Mounting a TV/Artwork       28         Flush Mounted TV/Artwork       29
Heat Release 23 Air Intake 26 Mounting a TV/Artwork 28 Flush Mounted TV/Artwork 29 Recessed TV/Artwork 30
Heat Release       23         Air Intake       26         Mounting a TV/Artwork       28         Flush Mounted TV/Artwork       29         Recessed TV/Artwork       30         Access Panel       31
Heat Release       23         Air Intake       26         Mounting a TV/Artwork       28         Flush Mounted TV/Artwork       29         Recessed TV/Artwork       30         Access Panel       31         Cavity Area Minimum       31
Heat Release       23         Air Intake       26         Mounting a TV/Artwork       28         Flush Mounted TV/Artwork       29         Recessed TV/Artwork       30         Access Panel       31         Cavity Area Minimum       31         Recessed Partial Ledge       31
Heat Release       23         Air Intake       26         Mounting a TV/Artwork       28         Flush Mounted TV/Artwork       29         Recessed TV/Artwork       30         Access Panel       31         Cavity Area Minimum       31         Recessed Partial Ledge       31         Step-by-Step Cavity Construction       33
Heat Release       23         Air Intake       26         Mounting a TV/Artwork       28         Flush Mounted TV/Artwork       29         Recessed TV/Artwork       30         Access Panel       31         Cavity Area Minimum       31         Recessed Partial Ledge       31         Step-by-Step Cavity Construction       33         Cold Climate Insulation       34
Heat Release       23         Air Intake       26         Mounting a TV/Artwork       28         Flush Mounted TV/Artwork       29         Recessed TV/Artwork       30         Access Panel       31         Cavity Area Minimum       31         Recessed Partial Ledge       31         Step-by-Step Cavity Construction       33         Cold Climate Insulation       34         Finishing       35
Heat Release       23         Air Intake       26         Mounting a TV/Artwork       28         Flush Mounted TV/Artwork       29         Recessed TV/Artwork       30         Access Panel       31         Cavity Area Minimum       31         Recessed Partial Ledge       31         Step-by-Step Cavity Construction       33         Cold Climate Insulation       34         Finishing       35         Flush Installation       35
Heat Release       23         Air Intake       26         Mounting a TV/Artwork       28         Flush Mounted TV/Artwork       29         Recessed TV/Artwork       30         Access Panel       31         Cavity Area Minimum       31         Recessed Partial Ledge       31         Step-by-Step Cavity Construction       33         Cold Climate Insulation       34         Finishing       35         Flush Installation       35         Recessed Installation       36
Heat Release       23         Air Intake       26         Mounting a TV/Artwork       28         Flush Mounted TV/Artwork       29         Recessed TV/Artwork       30         Access Panel       31         Cavity Area Minimum       31         Recessed Partial Ledge       31         Step-by-Step Cavity Construction       33         Cold Climate Insulation       34         Finishing       35         Flush Installation       35         Recessed Installation       36         Gas Pressures       37
Heat Release       23         Air Intake       26         Mounting a TV/Artwork       28         Flush Mounted TV/Artwork       29         Recessed TV/Artwork       30         Access Panel       31         Cavity Area Minimum       31         Recessed Partial Ledge       31         Step-by-Step Cavity Construction       33         Cold Climate Insulation       34         Finishing       35         Flush Installation       35         Recessed Installation       36         Gas Pressures       37         Routing the Gas Line       38

Pilot and Thermocouple Maintenance	49
General Flue Requirements	50
Flue Configurations	51
Flue Restrictors	54
Restrictor Sizing Guidelines	54
Flue Clearances	57
Flue Installation and Clearances	58
Vertical Clearance Diagram	58
Flue Termination Drawings	59
Flue Maintenance	60
Chimney Shroud	61
Fireplace Heat Barrier	63
Removal / Assembly of the Double Glass Heat Barrier and Inner Glass	64
Removing/Assembling the Back Panel	72
75/65 Front Bricks Installation	76
Traditional Bricks Installation	78
Electrical Requirements	82
Power Outage	82
Pairing the Remote and Receiver	82
Wiring Diagram	83
Home Automation Wiring Diagram	86
Interior Design Media	87
Media Placement Guidelines	87
Media Placement Guidelines	88
Arrangement of pebbles	90
Arrangement of crystals	91
Operation	92
10-Button Remote Control Handset	93
Operating Instructions	93
Wall Switch	95
Operating Instructions	95
General Maintenance	97
Appendix A: Fireplace Troubleshooting Guide	98
Pre-troubleshooting Checklist	99
Normal Sequence of Fireplace Operation	101
Troubleshooting Pilot Problems	103
Spark But No Pilot	103
No Spark to the Pilot	103
Pilot Turns Off After Igniting But Before Burner Turns On	103
Pilot Turns Off After Igniting and After Burner Turns On	104
Troubleshooting Thermocouple Problems	105
Checking the Thermocouple	105
Testing the Thermocouple	105

Troubleshooting Main Burner Problems	106
Troubleshooting Flame Issues	107
Troubleshooting Beeping	108
Mertik Maxitrol External Source Operation	110
Appendix E: ORTAL Factory Recommended Service Checklist	112
ORTAL Product Service Log	113
Appendix F: Warranty Policy	114
Manufacturer Contact Information	
Table of Figures	40
Figure 1: Thermocouple Injector	
Figure 2: Double Glass Heat Barrier: Parts	
Figure 3: Back Panel: Parts	
Figure 4: Components for Front Bricks Installation	
Figure 5: Components for Traditional Bricks Installation	
Figure 7: Log Media Placement for Clear 75 H F/RS/LS/TS/TU/SC, 170 H F/RS/LS/TS/TU	
Figure 8: Log Media Placement for Clear 110 H F/RS/LS/TS/TU/SC, 170 H F/RS/LS/TS/TU	
Figure 9: Log Media Placement for Clear 150 H F/RS/LS/TS/TU/SC, 170 H F/RS/LS/TS/TU	
Figure 10: Log Media Placement for Clear 200 H F/RS/LS/TS/TU/SC, Clear 200 F/RS/LS/TS/TU/SC	
Figure 11: ON/OFF and Manual Pilot Valve Switches	
Figure 12: Valve/Receiver Wires and Interrupter Block	
Figure 13: ORTAL Remote Control	101



## Fireplace Safety Information and Warnings

This section provides safety guidelines and instructions. It is important to SAVE THESE INSTRUCTIONS and to make yourself fully aware of all the safety protocols and the many features of the ORTAL room sealed gas fireplace appliance.

- **INSTALLER:** Leave this manual with the appliance.
- **OWNER:** Keep this manual for future reference.



NOTE: ALL the warnings and instructions below apply to ALL the models.





#### WARNING – HEAT BARRIER

A barrier designed to reduce the risk of burns from hot viewing glass is provided with this appliance and shall be installed. If the barrier becomes damaged, the barrier shall be replaced with the manufacturer's barrier for this appliance. Any safety screen, guard, or barrier removed for servicing the appliance must be replaced prior to operating.

THE BARRIER IS FITTED TO THIS APPLIANCE TO REDUCE THE RISK OF FIRE OR INJURY FROM BURNS AND NO PART OF IT SHOULD BE PERMANENTLY REMOVED.

FOR PROTECTION OF YOUNG CHILDREN OR THE INFIRM, A SECONDARY GUARD IS REQUIRED



## WARNING – FIREPLACE TEMPERATURE

Due to high temperatures, the appliance should be located out of traffic and away from furniture and draperies.

Children and adults should be alerted to the hazards of high surface temperature and should stay away to avoid burns or clothing ignition.

Clothing or other flammable material should not be placed on or near the appliance.

#### Young children should be carefully supervised when they are in the same room as the appliance.

Toddlers, young children and others may be susceptible to accidental contact burns. A physical barrier is recommended if there are at-risk individuals in the house. To restrict access to a fireplace or stove, install an adjustable safety gate to keep toddlers, young children and other at-risk individuals out of the room and away from hot surfaces.



#### **!** WARNING – GLASS HANDLING

The glass must ONLY be removed by an authorized installer. The authorized technician should ONLY remove the glass with the suction cups supplied by the manufacturer. To prevent damage to the glass edges, lower the glass to rest in a safe place.

Follow these guidelines for glass handling:

**Ortal Installation Manual: (V1.6)** 

- **Step 1:** Prepare a safe place for the glass to rest.
- **Step 2:** Remove the glass using the suction cup.
- **Step 3:** The glass can now be rested safely.



#### WARNING – IF YOU SMELL GAS

If you smell gas, take the following action immediately:

- Do not try to light any appliance.
- Do not touch any electrical switch.
- Do not use any phone in your building.
- Call your gas supplier from a neighbour's phone, and follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.



#### WARNING – INSTALLATION AND OPERATION

The room sealed system appliance must be installed as an OEM installation in manufactured homes or an aftermarket permanently located, or a mobile home, where not prohibited by local codes.

The appliance must be installed in accordance with the Manufacturer's instructions and the Manufactured Home Construction and Safety Standard.

If the information in these instructions are not followed exactly, a fire or explosion may result, causing property damage, personal injury or loss of life.

Do not store or use gasoline or other flammable vapours and liquids near this appliance.



## **!** WARNING – INSTALLATION AND SERVICE

Installation and repairs must be done by an authorized installer service agency or gas supplier. The appliance should be inspected before use and at least annually by a professional service person. More frequent cleaning may be required due to excessive lint from carpeting, bedding material, etc. It is imperative that control apartments, burners and circulating air passageways of the appliance be kept clean.

Any alteration to the product that causes soot or carbon to form and results in damage is not the responsibility of the manufacturer.



## WARNING – GAS APPLIANCE

This appliance is for use only with the type of gas indicated on the rating plate. These appliances are not convertible for use with other gases, unless a certified kit is used and the conversion is performed by an authorized technician.



#### **!** WARNING

- DO NOT USE AN UNLINED MASONRY CHIMNEY AS THE FLUE FOR THIS APPLIANCE
- PRIMARILY A DECORATIVE AND NOT A HEATING APPLIANCE
- THE GUARD IS FITTED TO THIS APPLIANCE TO REDUCE RISK OF FIRE OR INJURY FROM BURNS AND NO PART OF IT SHOULD BE PERMANANTLY REMOVED. FOR PROTECTION OF YOUNG CHILDREN OR THE INFIRM, A SECONDARY **GUARD IS REQUIRED.**
- THIS APPLIANCE REQUIRES FRESH AIR TO OPERATE SAFELY



WARNING: DO NOT USE AN UNLINED MASONRY CHIMNEY AS THE FLUE FOR THIS APPLIANCE

## **Operating Warnings**

ORTAL room sealed gas fireplace heaters are sealed combustion, air-circulating gas fireplaces designed for residential applications.

For your safety, please read the following warnings carefully before lighting your fireplace. If you do not follow these instructions exactly, a fire or explosion may result, causing property damage, personal injury or loss of life.



## WARNING –DO NOT OPERATE YOUR APPLIANCE IF:

- The glass is NOT properly secured in place
- Connection points are not sealed (for appliances with glass-to-glass connections)
- Glass is cracked
- You smell gas
- Any part of the appliance has been under water
- You have any doubt about safe operation of the unit

If any part has been under water, do not use the appliance. Immediately call an authorized, professional service technician to inspect the appliance and to replace any parts of the control system and any gas controls, which have been under water.

#### Certifications and Codes

The appliance has been certified for use with either natural gas (NG) or Universal LPG, and NOT for use with solid fuels.

These gas fireplace appliances are AGA certified and approved for indoor use. They can be specialized with certain requirements for indoor-outdoor use (i.e., tunnel models). For indoor installation, they must be installed while maintaining required clearances. Installation is recommended in living spaces such as bedrooms, living rooms, great rooms, etc. The appliance is not approved for closet installation.

The appliance must be installed according to ORTAL requirements in addition to any local codes that may apply. The appliance must be properly connected to an approved flueing system. Refer to the specific appliance to determine flue size and pathway requirements. In addition, adhere to the following pre-installation guidelines:

- Approved flue system manufacturers are:
  - DuraVent
- Consult the authority having jurisdiction to determine the need for a permit **PRIOR** to starting the installation.
- It is the responsibility of the installer to ensure that this fireplace is installed in compliance with the manufacturer's instructions and all the applicable codes.
- Before starting, take careful note of **ALL** the **WARNINGS** in this manual.

## Product List: Models and Burners

The following table lists burners and flueing for models using the installation codes for decorative flued gas fireplaces. Adaptors are not required.

MODELS: FR/RS/LS/TS/SA/H				
Model	Clear 75	x65, Clear 75H	Clear 110 - Clear 130	
Gas	NG	Propane	NG	Propane
Burner Size	45	45	100	100
Injectors	Marked 650: with 7x0.950mm orifice	Marked 220: with 7x0.550mm orifice	Marked 1200: with 7x1.275mm orifice	Marked 260: with 7x0.575mm orifice
Nominal gas Consumption	26 MJ/h	20 MJ/h	37 MJ/h	30 MJ/h
Inlet Pressure	1.13kPA	2.75	1.13kPA	2.75
Manifold pressure	0.82kPA	1.80kPA	0.73kPA	2.70kPA
Turndown Pressure	0.23kPa	0.88kPA	0.26kPa	1.20kPA
Direct Flueing	100/150mm	100/150mm	130/200mm	130/200mm

MODELS: FR/RS/LS/TS/SA/H				
Model	Clear 150/170		Clear 200/250	
Gas	NG	Universal LPG	NG	Universal LPG
Burner Size	135D	135D	160D	160D
Injectors	Marked 1200: with 7x1.25mm orifice Marked 1400: With single 3.9mm orifice	2xMarked 260 with 7x0.58mm orifice	Marked 800: with 7x1.05mm orifice Marked 1400: With single 3.8mm orifice	2xMarked 260 with 7x0.78mm orifice
Nominal gas Consumption	55 MJ/h	50 MJ/h	52 MJ/h	40 MJ/h
Inlet Pressure	1.13kPA	2.75kPa	1.13kPA	2.75kPa
Manifold pressure	0.61kPA	2.3kPa	0.50kPA	1.6kPa
Turndown Pressure	0.22kPa	1.5kPa	0.22kPa	0.87kPa
Direct Flueing	130/200mm	130/200mm	130/200mm	130/200mm

The following table explains the acronyms used.

FR	Front	TU	Tunnel
RS	Right Side	н	High
LS	Left Side	TR	Traditional
TS	Three Sides	SA	Console Appliance
SC	Space Creator		

#### Prior to Installation

#### Locate the Fireplace

Keep the following factors in mind when selecting a location for the fireplace:

- Fireplace clearance requirements (review "General Clearances" sections).
- Heat release and air intake requirements (review "Heat Release" and "Air Intake" sections).
- Adequate space for servicing.
- Access panel recommendations (review "Access Panel" section).
- Minimum vertical flue rise, allowed horizontal lengths, and elbow usage (review "Flueing" section).
- Framing and finishing requirements (review "Framing" and "Finishing" sections).
  - Front wall installation and finishes to be completed after fireplace and flue installation (review "Step-By-Step Cavity Construction" section).
- Floor or Platform requirements (review "Platform" section).

## Fireplace Installation

Use the following guidelines to ensure a smooth installation. The installation sequence is divided into three phases: Planning, Installation, and Start-up.

#### First Trip to Site: Planning

Consult with the contractor and go over all requirements:

- Cavity framing requirements.
- 9 mm Cement Sheet (or equivalent) requirements.
- Heat release requirements.
- Air Intake requirements (if applicable).
- Access panel size and location.
- Gas and electric specs and location.
- Flue configuration.
- Finishing details.



NOTE: Provide the contractor with a printed copy of the "Building Checklist" and review requirements with them.

#### Second Trip to Site: Installation

- Confirm the following items are properly located and built to specification:
  - Framing (with 9 mm Cement Sheet)
  - **Platform**
  - Gas and electric
  - Access panel
  - Heat release
  - Air intake (if applicable)
- Clear a path free of any possible obstruction to carry in the fireplace.
- Unpack the fireplace and set in place.
- Secure the fireplace by attaching the seismic brackets to the framing. See "Securing the Fireplace" section below.
- Remove plastic sleeve covering pilot tube and electrical wires.
- Remove all zip ties.
- Optional: Remove gas and electrical components from metal shipping plate if desired.
- Move the components to the access panel location. Be mindful of the routing for future service needs.
- Verify the light grounding cable is connected to the firebox.
- Install the flue components. See "Flue Installation" section below.
- Review the front wall requirements (see "Step-By-Step Cavity Construction" section) and finishing details with the contractor.
- Protect the fireplace and components from damage.




#### WARNING: LIP INSTALLATION IN H FIREPLACES

To ensure the glass is removable after installation, Magnetic Screw (Part #M03) under the fireplace lip must be secured tightly to the firebox and screwed in as far as possible prior to installation of framing and finish material. If the magnet is not completely screwed down into the firebox, the lip will sit ajar to the firebox, preventing glass removal.

#### Securing the Fireplace

The fireplace has nailing flanges attached to the face of the fireplace (see figures below). The nailing flanges are to be attached into the framing upon installation. It is crucial to the finishing that the fireplace is stable, level, and plumb. For added stability (though not required), re-use the shipping brackets to secure the legs of the fireplace to floor/platform.



Nailing Flanges for Front Facing

Nailing Flanges for Corner (RS/LS)

Nailing Flanges for Three Side


#### Securing the Fireplace

During shipping, two L-shaped seismic brackets are attached from the fireplace to the crating for stabilization. These brackets must be re-used during installation to secure the fireplace to the back (or side) framing. It is crucial to the finishing that the fireplace is stable, level, and plumb. For added stability (though not required), re-use the leg shipping brackets to secure the legs of the fireplace to floor/platform.

#### Flue Installation

Flueing must be installed according to the requirements detailed in the "Flueing" section of this manual in conjunction with the flue system manufacturer's installation instructions. Flueing must be supported by the support surrounding and not by the fireplace. Each offset (elbow) must be strapped to reduce movement or possible disconnection.

The first section of flueing must be secured to the fireplace starter collar with a minimum of 3 sheet metal screws no longer than 13 mm. DO NOT use silicone to seal the sections. If sealing is required by the flue manufacturer or local code, use Mil-Pac sealant.



Seismic Bracket

#### Third Trip to Site: Start-up

- Perform a visual inspection to confirm that all work was completed correctly and per specification.
- Confirm that gas and electric are properly connected and live and operating the specs specified within this manual.
- Remove the safety barrier and glass and clean the inside of the fireplace.
- Install the Interior Design Media (if desired) on the burner as specified in "Interior Design Media" section.
- Confirm the fireplace is operating properly.
- Check remote-control setup.
- Remove protective layer from glass.
- Clean glass.
- Reinstall the glass and safety barrier.
- Review operation of the fireplace and remote control with the owner.
- Set up return visit to clean glass after the Initial Burning Period (see "Post-Installation" section below).

#### Working with Glass Panels

Inner glass panel is 5mm ceramic glass. For fireplaces with a double glass heat barrier, exterior glass panel is 5 mm tempered glass.

Silicone comes pre-applied to any glass-to-glass connections (multi-sided models), on both sides of the glass. Keep the following guidelines in mind when handling silicone and glass panels:

The purpose of the silicone is to create a gasket, not to "glue" the glass panels together. When placing glass panels, ensure that the glass is fully in place and that the silicone is filling the space between the glass panels. Place the front (or centre) panel in place first and then slide the side panel into place so that the silicone edge touches the glass edge.

#### Post-Installation

Complete the following post-installation steps upon 4<sup>th</sup> trip to site.

#### **Initial Burning Period**

There is a 12-hour minimum burning period following installation of the fireplace. This 12-hour period must include a minimum of 4 consecutive hours of continuous burning. During this time, the owner or installer may notice:

- The glass developing a white or "cloudy" residue.
- An unusual smell

Both the residue and the smell are due to the paint on the fireplace metal heating and "burning off". This is normal. The cloudiness and odour will disappear after the 12-hour period elapses and the installer returns to service the fireplace and complete start-up.

#### Final Inspection Procedure

When the 12-hour burning period is complete, the installer must return and perform the final inspection, which includes:

- Cleaning the glass with a ceramic glass cleaner (otherwise the white residue will remain)
- Checking the interior media setup
- Checking for gas leaks
- Checking for spillage
- Adjusting the restrictor (if necessary)
- Performing an overall check to make sure that all systems and components is working properly.

When these activities are complete, initial start-up is concluded and the fireplace may be operated by the owner.

#### Final Checks and User Instruction

Before releasing the fireplace to the customer for use without installer supervision, the installer must ensure that the fireplace is burning correctly. In addition, the installer must review and explain the following to the owner:

- Safety warnings
- Fireplace operation
- Warranty requirements
- Maintenance requirements
- Glass and firebox components are hot during and after operation.
- If any questions or concerns arise, owner must contact the local Ortal dealer/installer for support.

## **Building Checklist**

The following building checklist is a quick reference for a typical Ortal Built-In Series fireplace installation. This list is not exhaustive and does not supplement thorough review of the installation manual.

- ☑ **Fireplace Location:** Ensure the location allows for min. 90 cm clearance from viewing area to combustibles and 30 cm to noncombustibles. Make sure a clear path is established to allow the fireplace to be safely transported to installation location.
- ☑ Flueing: Confirm flue size 100/150, flue clearance (25 mm on sides and bottom, 80 mm on top), flue configuration, and termination location.
- ☑ **Height from Floor:** Fireplace leg height is 25 cm (to bottom viewing area). Legs cannot be removed/altered. If desired viewing area location on the wall is higher than 250 mm, a platform can be built for the fireplace to stand on.
- ☑ Cavity Floor/Platform: Fireplace can stand on the Cavity floor or a platform. Floor or platform must be able to bear the weight of the fireplace. It can be constructed out of wood, concrete, metal, or any other solid materials (not required being non-combustible).
- ☑ Cavity Construction: No materials can be attached directly to the fireplace (exception: 9 mm Cement Sheet). The area of the cavity interior must meet minimum cavity area requirements (depending on the model). All cavities require a heat release, and double glass fireplaces require and air intake (details below).
- ☑ **Framing:** Adhere to minimum framing dimensions (or greater). Keep min. 50 mm clearance from back and sides (as applicable by model) of fireplace to any material. The first 46 cm above the top of the fireplace viewing area must always be noncombustible framing. Maintain min 7 mm clearance from front face of fireplace and front metal offset to the framing. Maintain min. 10 cm space between air flues at top of fireplace to any material. For recessed fireplaces, do not exceed 45 cm max. front overhang depth limit. Side overhang depth is unlimited. No material is permitted to extend past the metal lip surrounding the fireplace viewing area to allow for glass removal.
- ☑ **Drywall Requirements:** One layer of 9 mm Cement Sheet (or equivalent) must be installed on the exterior of the Cavity framing.
- ☑ TV/Artwork: TV/Art must be min.100 mm above top of fireplace viewing area.
- ☑ **Gas Supply Line and Power Location:** Locate gas line with manual shut off according to local code. Power provided by single gang 240V outlet in same area as gas line.
- Access Panel: Access panel highly recommended to access gas and electrical components for servicing. Depending on the model, access panel can be placed at side or back of the fireplace within 1 metre of the pilot. Access panel or some other form of clear access to the Cavity is required for power-flued fireplaces. Size recommendation: as large as possible depending on application. Min. recommended size 25 cm x 25 cm.
- ☑ Heat Release: Crucial for Cool Wall Technology. Must start within 15 cm (max.) from the Cavity's ceiling. Heat release must meet minimum size (depending on the model) of net free air space. Height of the heat release must not exceed ¹/₃ of the width.
- Air Intake: Only required for double glass heat barrier. Must be located below glass level, according to drawing. Air intake must meet minimum size (depending on the model) of net free air space.
- Finishing: For finishes flush to the fireplace, no clearances are required. For finishes where the fireplace is recessed to the finish, maintain 3 mm from the finish to the front face of the fireplace.

## Framing

Fireplace cavity may be framed with either combustible (typically wood studs) or non-combustible framing (typically metal studs). **Any framing within 45 cm from the top of the fireplace glass (viewing area) must be non-combustible.** This does not apply to the framing to the back or side(s) of the fireplace; these may be combustible.


The fireplace is non-load bearing. The framing of the fireplace Cavity must be designed to carry the entire weight of the wall and finish material. Surrounding material must not transfer weight to the fireplace (exception: 9 mm Cement Sheet or equivalent), or be connected in any way to the fireplace.

No material is permitted to extend past the metal lip surrounding the fireplace viewing area. This area must be unobstructed to allow the heat barrier and inside glass panel to be removable.

IMPORTANT: To ensure the glass is removable after installation, Magnetic Screw (Part #M03) under the fireplace lip must be secured tightly to the firebox and screwed in as far as possible prior to installation of framing and finish material. If the magnet is not completely screwed down into the firebox, the lip will sit ajar to the firebox, preventing glass removal.


#### Framing Dimensions

The following diagrams are for illustrative purposes only. There are multiple approved installation scenarios. A flush application is not the only permitted application. The fireplace may be recessed into the wall. Refer to diagrams and values below and in the following pages for details.




WARNING – MAINTAIN AIR FLOW CLEARANCE: Firebox top flue must have minimum 10 cm of clearance to any material achieve sufficient airflow. Failure to do so could result in improper fireplace operation, property damage, or physical injury. Review "General Clearances" section prior to framing to ensure all clearances are followed.

Model	Dimension A	Dimension B	Dimension C	Dimension D
7565 F	1360 mm	1000 mm	475 mm	
75H F	1330 mm	900 mm	640 mm	
110 F	1115 mm	1355 mm	560 mm	
110H F	1300 mm	1355 mm	560 mm	
130 F	1115 mm	1550 mm	560 mm	
130H F	1300 mm	1550 mm	560 mm	
150 F	1115 mm	1800 mm	560 mm	Defende flue
150H F	1300 mm	1800 mm	560 mm	Refer to flue specifications for
170 F	1115 mm	2000 mm	560 mm	dimensions and
170H F	1300 mm	2000 mm	560 mm	clearances
200F	1115 mm	2250 mm	560 mm	
200H F	1300 mm	2250 mm	560 mm	
250 F	1115 mm	2750 mm	560 mm	
250H F	1300 mm	2750 mm	560 mm	
TR 90	1630 mm	1230 mm	710 mm	
TR 110	1700 mm	1400 mm	710 mm	



WARNING – MAINTAIN AIR FLOW CLEARANCE: Firebox top flue must have minimum 10 cm of clearance to any material achieve sufficient airflow. Failure to do so could result in improper fireplace operation, property damage, or physical injury. Review "General Clearances" section prior to framing to ensure all clearances are followed.

Model	Dimension A	Dimension B	Dimension C	Dimension D
75H RS/LS	1350 mm	850 mm	650 mm	
110 RS/LS	1125 mm	1350 mm	560 mm	
110H RS/LS	1275 mm	1350 mm	560 mm	
130 RS/LS	1125 mm	1500 mm	560 mm	
130H RS/LS	1275 mm	1500 mm	560 mm	
150 RS/LS	1125 mm	1750 mm	560 mm	Refer to flue specifications
150H RS/LS	1275 mm	1750 mm	560 mm	for dimensions
170 RS/LS	1125 mm	1950 mm	560 mm	and clearances
170H RS/LS	1275 mm	1950 mm	560 mm	
200 RS/LS	1125 mm	2200 mm	560 mm	
200H RS/LS	1275 mm	2200 mm	560 mm	
250 RS/LS	1125 mm	2700 mm	560 mm	
250H RS/LS	1275 mm	2700 mm	560 mm	



WARNING – MAINTAIN AIR FLOW CLEARANCE: Firebox top flue must have minimum 10 cm of clearance to any material achieve sufficient airflow. Failure to do so could result in improper fireplace operation, property damage, or physical injury. Review "General Clearances" section prior to framing to ensure all clearances are followed.


Model	Dimension A	Dimension B	Dimension C	Dimension D
75H TS	1350 mm	780 mm	650 mm	
110 TS	1125 mm	1240 mm	560 mm	
110H TS	1275 mm	1240 mm	560 mm	
130 TS	1125 mm	1410 mm	560 mm	
130H TS	1275 mm	1410 mm	560 mm	
150 TS	1125 mm	1660 mm	560 mm	Refer to flue specifications
150H TS	1275 mm	1660 mm	560 mm	for dimensions
170 TS	1125 mm	1860 mm	560 mm	and clearances
170H TS	1275 mm	1860 mm	560 mm	
200 TS	1125 mm	2100 mm	560 mm	
200H TS	1275 mm	2100 mm	560 mm	
250 TS	1125 mm	2600 mm	560 mm	
250H TS	1275 mm	2600 mm	560 mm	

#### Cavity Floor/Platform

The fireplace must be installed on a flat, solid, continuous surface. Surface can be wood, concrete, metal, and other typical solid floor types. Surface material is not required to be non-combustible.

Fireplace leg height is 25 cm (measured to bottom of viewing area). Legs cannot be removed, cut, or adjusted.

**Raised Platform Option:** To raise the fireplace higher than 25 cm height, build a platform for the fireplace to stand on. Platform must be stable and able to bear the full weight of the fireplace. Platform can be constructed out of wood, concrete, metal, or any other solid materials. Platform material is not required to be non-combustible.



NOTE: An air intake is necessary to incorporate into the platform depending on the design. See "Air Intake for a Platform" for details.

#### Hearth Extension

A hearth extension is not required. Any hearth extension used is for appearance only and does not have to conform to a standard hearth extension installation requirement.

#### General Clearances

#### **Viewing Area Clearances**

The viewing area clearance zone is an area that extends perpendicular from the fireplace viewing area. The depth of the viewing area clearance zone depends on the combustibility of the material in question. Distance is measured from the fireplace heat barrier.

Non-Combustible Materials Must be minimum 300 mm from fireplace viewing area.

Combustible Materials Must be minimum 920 mm from fireplace viewing area.


Materials (including combustible flooring and combustible finish material) are permitted below and around the viewing area clearance zone.

IMPORTANT NOTE: When placing material near the glass, take care to consider fireplace serviceability. It is strongly recommended that any items/materials placed in front of the front (long) glass be movable for easy access to the fireplace during servicing. Recommendation does not apply to side (short) glass(es).


Maintain a 50 mm clearance from the back and/or side of the fireplace (depending on the model) to any material.

Viewing area clearances per model		
Front	Three side	
W. and O'comments		
Corner: Right side	Corner:Left side	
	OC dette Contained	


#### **Firebox Clearance Per Model**




Front & Traditional



Three Side




Corner: Left Side



Corner: Right Side

#### Clearance to Cavity Ceiling

Maintain a **46 cm** clearance from the top of the fireplace viewing area to the lowest point of the ceiling or to any building materials.



**Minimum Cavity Ceiling Clearance Diagram** 

## NOTES:


A heat release is required for every installation, but it is not required to be split between the two sides of the Cavity as shown in the diagram above. It is shown in this diagram for illustrative purposes only. See the "Heat Release Requirements" section for details.

Clearance around the flue pipe must be maintained

(25 mm clearance on the sides and bottom, 75 mm on top). See the "Error! Reference source not found.

#### Air Flow Clearance

A **100 mm** clearance from the heat barrier flue openings along the top of the fireplace is required. Framing and building material is **NOT** permitted in this area. Doing so will block the flues and cause the entire surrounding to overheat.



NOTE: It is acceptable if the flat stud immediately above the fireplace hangs over heat barrier flues *slightly* when using standard metal framing (as shown in diagram above).


#### Zero-Clearance Stand-Offs

The fireplace has zero-clearance stand-offs fastened to the body of the fireplace as shown in the figures below. Stand-offs must be fully extended upon installation.

<u>Heat Shield</u>: Attached to the top front part of the fireplace. It is foldable at the attachment site on top of the fireplace and  $^2/_3$  to the top of the shield. The heat shield serves to direct the heat coming out the of the heat barrier vents at the top of the fireplace and maintains clearance to the vent pipe.

<u>Side & Back Framing Stand-offs</u>: Attached to the sides and back of the fireplace. These stand-offs keep enough distance from the fireplace to the framing to allow for proper airflow inside the chase. These stand-offs can directly touch combustible framing.

<u>Front Framing Stand-offs</u>: Attached to the front top portion of the fireplace above the glass viewing area. It keeps a clearance above the heat barrier vents on the top of the fireplace to ensure proper air flow inside the chase. The top of this stand-off can directly touch combustible framing. Any framing in front of the stand-off must be non-combustible.





#### Framing Clearance

#### Clearance to a Side Wall

The fireplace viewing area is zero-clearance to a sidewall. A sidewall is defined as a wall that meets the viewing area at a 90° angle.







## Alcove Side Walls (top view)

## Corner Side Walls (top view)


The temperature on the sidewall can get as high as 65°C above ambient temperature. While the fireplace certification allows for this temperature variance, building and finish materials will have their own limitations. Consult the material manufacturer to ensure the material can safety withstand this temperature range.

This information does not apply to a wall that is constructed in front of the viewing area. For materials that will be in front of a main or side viewing area, please refer to the "Viewing Area Clearances" section.

#### Maximum Overhang Depth

Overhang depth of a recessed fireplace must not exceed the clearances shown in the diagrams below. Overhang depth is measured from the edge of the fireplace lip to the out-most part of the wall (including finish material).

Bottom recess (or "hearth extension") has no minimum or maximum depth requirement. If bottom recess depth exceeds 30 cm, ensure the structure is capable of supporting the weight of a fireplace technician for servicing.



#### Heat Release

A heat release is an opening in the fireplace Cavity that allows the heat inside the Cavity to passively circulate into an interior room. This heat is generated convectively as the fireplace heats up. It is separate from exhaust heat produced at the combustion chamber of the fireplace. For safety purposes, a **heat release is required** to keep the wall around the fireplace cool.

#### **Heat Release Requirements**

- The heat release must be located at or near the top of the fireplace Cavity and **start within** 15 cm (0-15 cm max) of the Cavity ceiling/firestop. It can start at the Cavity ceiling. It can be located on the front, sides or back of the Cavity. It can be released into any interior space that shares a wall with the Cavity.
- Minimum heat release size requirement depends on heat release orientation:

Fireplace Series	Horizontal Heat Release	Vertical Heat Release
75	Minimum 320 cm <sup>2</sup> . of free air space	Minimum 1000 cm <sup>2</sup> . of free air space
110-130	Minimum 800 cm <sup>2</sup> . of free air space	Minimum 1000 cm2. of free air space
150-200	Minimum 1300 cm <sup>2</sup> of free air space	Minimum 1700 cm <sup>2</sup> . of free air space
250	Minimum 1600 cm <sup>2</sup> of free air space	Minimum 2100 cm <sup>2</sup> . of free air space

<sup>\*</sup> Heat release requirements do not apply to Stand-alone (Console Appliance) fireplaces.


- For horizontal heat releases only, the height of the heat release must not exceed 1/3 of the width. (This does not apply to vertical heat releases.)
- The space the heat release flues into must have a minimum volume of 5.2 cm³.
- The heat release can be in the form of (but not limited to) a louvered ventilation grille, gap, or reveal.
  - For louvered/perforated ventilation grilles, the net free air space allowed in the louvered area must be equal or greater than the minimum number of square centimetres required per fireplace.
- The interior area of the narrowest part of the fireplace Cavity (in square centimetres) must never be less than your required heat release size (see "Cavity Area Minimum" section for details).
- The heat release cannot be flued outdoors or to an unconditioned space.




NOTE: An angled heat release is not permitted.

The following diagrams are examples of potential heat release options. These drawings serve as illustrative purposes only.

#### Horizontal Heat Release



**Reveal Heat Release** 





**Louvered Grille Heat Release** 

#### Vertical Heat Release: Split Front

The heat release is oriented vertically and split between the two sides of the Cavity.


# Vertical Heat Release: Full Side The heat release is oriented vertically. Entire heat





## Sprinkler Clearance to Heat Release

In a situation where a sprinkler head is near the heat release, the sprinkler head must be minimum **600 mm** (linear length) from any point of the heat release opening.




#### Air Intake


When installing a fireplace with a double glass heat barrier, it is essential to maintain cool airflow between the double glass panels. For this purpose, an opening must be provided toward the bottom of the wall to allow the double glass fans to circulate room air through the glass panels and up into the Cavity. This opening, called an air intake, needs to be made before closing the wall surface below the fireplace. Air intake must meet the minimum size requirement.


Fireplace Series	Air Intake
75	Minimum 320 cm <sup>2</sup> . of free air space
110-130	Minimum 800 cm <sup>2</sup> . of free air space
150-200	Minimum 1300 cm <sup>2</sup> . of free air space
250	Minimum 1600 cm <sup>2</sup> . of free air space

The air intake can be in the form of a louvered/perforated ventilation grille, gap, or toe-kick (reveal). For louvered ventilation grilles, the net free air space allowed in the louvered area must be equal or greater than the minimum number of square centimetres required per fireplace.

The entire air intake must be located at or below the level of the double glass fans. The air intake is not required to be on the front wall of the fireplace. The air intake cannot be on a wall that allows air from outside the house directly into the fireplace Cavity. Air must be from a conditioned space.







NOTE: Please refer to the "Platform" section for details on platform construction.

#### Mounting a TV/Artwork

Ortal's Cool Wall Technology is a technique that reduces the convective heat from the fireplace and prevents heat build-up inside the fireplace Cavity, mitigating any damage that may result from the wall reaching high temperatures. Ortal's Cool Wall system enables the option of safely installing artwork, a TV, or other similar electronic components above the fireplace by reducing the wall temperature above the fireplace.

Location	Wall Temperature
0-15 cm above fireplace	38°C - 49°C
15-30 cm above fireplace	32°C - 38°C
30 cm above fireplace	27°C - 32°C

#### Maintain the following general requirements to mount a TV or artwork above the fireplace and prevent heat damage:


- Mount the TV or artwork at the minimum clearance above the top of the fireplace viewing area. Minimum clearance amount depends on flush or recessed installation. See sections below for more information.
- Wires inside the Cavity are not permitted to cross over the fireplace. Wires must be installed against a wall.

The decision to install a television above the fireplace is up to the discretion of the owner. TV and art manufacturers may specify that their product should not be installed on, near or above a heat source. Ortal will not be held liable for any adverse effects on a TV, artwork or other equipment located near the fireplace. It is the owner's responsibility to verify that their TV or artwork can withstand the wall temperatures as outlined in the above wall temperature chart.

The following diagrams can be used as a guide for customers who do decide to locate their TV and artwork above their fireplace. These drawings illustrate ways of reducing the amount of heat impact to the area surrounding the fireplace.

# Flush Mounted TV/Artwork

When the TV is mounted on a wall that is flush to the fireplace, the TV must be at least **10 cm** from the top of the fireplace glass viewing area. Ensure all clearances are maintained. See diagram below for details.




NOTE: Flue clearances must be maintained. See "General Clearances" section for details.

# Recessed TV/Artwork

When the TV is mounted on a wall that recesses over fireplace, the TV must be at least **10 cm** from the top of the fireplace glass viewing area.

At 10 cm above the fireplace viewing area, maximum possible recess is 10 cm. A deeper recess will interfere with required clearances to flueing. Maximum possible recess increases at <30 cm above the viewing area when flueing is offset (as shown in diagram below).



NOTE: Flue clearances must be maintained. See "General Clearances" section for details.

#### Access Panel

An access panel is not required (see notes below for exception), but it is <u>highly recommended</u>. It allows for access to the fireplace's gas and electrical components for servicing.

NOTE: An access panel, or some other form of clear access, is required for power flued fireplaces. For servicing purposes, the power flue control box (located at the fireplace) must be easily accessible in a way that does not require removal of the fireplace glass.

Access Panel Size and Location Recommendations:

- Minimum of 25 cm x 25 cm in size
- Located within 90 cm of the pilot to the side or back of the fireplace (see "Routing the Gas Line")

The size and location of the access panel may vary, but in all cases, it must allow the technician to comfortably access and service the fireplace's gas and electrical components. These components are attached to the pilot on a flexible gas line and can be moved within 90 cm of the pilot (located at the centre front of the burner).

For ease of access, move the fireplace's gas and electrical components as close to the access panel as possible. If there is any distance between the access panel and the gas and electrical components, the access panel size must be increased accordingly. Prior to installation, fireplace dealers/installers should work with the owner, builder, project architects and/or interior designers to determine the best size and location of their access panel.

If an access panel cannot be incorporated, the alternative method of servicing the gas and electrical components is though the fireplace. This procedure requires removing the glass panel(s) and interior design media, and lifting the grill, burner, and bottom pressure release valve. This will increase service time and difficulty. An access panel is always preferred. Fireplace dealers/installers are advised to consult with their clients regarding the advantages and disadvantages of each service option.



NOTE: If local code requires an access panel, defer to local code requirements.

#### Cavity Area Minimum

To ensure the convective heat within the Cavity passively moves to the heat release at an optimal rate, all parts of the interior of the Cavity must at least the same size as the fireplace heat release (see "Heat Release" section to determine your model's required heat release size) at size at any given point. To determine if your Cavity meets this requirement, use the following equation at the narrowest part of the Cavity.


Cavity Area = (Cavity Length x Cavity Depth) - (Area of the Pipe)

#### Area of the Pipe:

100/150 flueing = 182 cm<sup>2</sup>

Used for Power Flueing only

If the heat release is split into 25/75 portions due to an oversized ledge, the Cavity only needs to be the size of 75% of the heat release because 25% of the heat is already being released at the ledge (see "Ledge Detail" section below for details).




Fireplace Cavity (Top View)

### **Recessed Partial Ledge**

A ledge over the top of a fireplace that is less than 60 cm from the top of the fireplace viewing area must maintain a minimum of 30 cm from the top of the viewing area to the bottom of the building material. Entire structure must be non-combustible (framing and finish).


If ledge surface area exceeds the values shown in the chart below, the heat release must be divided between the ledge and the Cavity ceiling: 25% at the ledge and 75% at the Cavity ceiling. This is referred to as an oversized partial ledge (see diagram below).

Fireplace Series	Maximum Ledge Surface Area
75*	A x B ≤ 1420 sq. cm.
110-130*	A x B ≤ 2200 sq. cm.
150-170	A x B ≤ 2650 sq. cm.
200	A x B ≤ 3350 sq. cm.
250	A x B ≤ 3750 sq. cm.



A = ledge depth, B= ledge width (Top View)

### Oversized Partial Ledge



**Oversized Partial Recessed Ledge Detail** 

NOTE: Cavity area minimum requirements must be met throughout the entire fireplace cavity. See "Cavity Area Minimum" section above for details.

### Step-by-Step Cavity Construction

The following checklist is a simplified overview of typical Cavity construction for a built-in fireplace installation. This list is not exhaustive and does not supplement thorough review of the installation manual.

### Step 1

### **BUILD BACK AND SIDE WALLS**

- ☑ Frame the back and side walls according to framing requirements.
- Build the platform (if necessary) to the desired height and install inside fireplace Cavity.
  - Platform must be stable and able to bear the full weight of the fireplace. Platform can be constructed out of wood, concrete, metal, or any other solid materials. Material is not required to be non-combustible.

### Step 2

#### INSTALL FIREPLACE AND FLUEING, RUN GAS AND ELECTRICAL

- ☑ Install the fireplace and flueing. This must be completed by an authorized Ortal dealer (unless otherwise authorized by Ortal with written approval).
- ☑ Move the gas valve and receiver unit to the designated access panel location. If the fireplace will not have an access panel, keep gas valve and receiver unit directly underneath the fireplace.
- ☑ Run gas and electric to the gas valve and receiver unit location.

### Step 3

#### **BUILD FRONT WALL**

- ☑ Install front Cavity wall:
  - Build front wall according to framing requirements.
  - Stand up the front wall and move into place.
  - Secure front wall to the rest of the Cavity structure.
- ☑ Cover the exterior of each wall (sides and front, and back if applicable depending on your design) with 9 mm Cement Sheet (or equivalent) and seal gaps with a non-combustible fire sealant.



Check to make sure constructed Cavity meets heat release and air intake (if applicable) requirements.

### Step 4

#### **APPLY FINISHES**

- Apply finishes and install accessories, following all clearances and building requirements.
- ☑ Ensure furniture and other combustible materials maintain a minimum 90 cm of clearance directly in front of the fireplace viewing area for both front and side viewing areas (as applicable).

### Cold Climate Insulation

Seal all cracks around your appliance with non-combustible material and wherever cold air could enter the room. It is especially important to insulate outside cavity between fastenings, and under the floor on which the appliance rests if the floor is above ground level. Gas line holes and other openings should be caulked or stuffed with un-faced fiberglass insulation.

If the fireplace is being installed on a cement slab, a sheet of plywood or other raised platform can be placed underneath to prevent cold transfer to the fireplace and into the room. It also helps to sheetrock inside surfaces and tape and caulk fire stops for maximum air tightness.

### Finishing

The following diagrams show various finish applications. **Diagrams apply to both combustible and non-combustible finish material.** 




### **IMPORTANT NOTES:**

- All recessed installations must comply with applicable maximum overhang limit and side wall clearances. See "Maximum Overhang Depth" and "Clearance to a Side Wall" sections for details.
- No material is permitted to extend past the metal lip surrounding the fireplace viewing area. This area must be unobstructed to allow the heat barrier and inside glass panel to be removable.
- MANUFACTURED STONE: A minimum 5 cm recess is suggested. Consult stone manufacturer for clearance requirements.

WARNING: Wood finish or floor/hearth extension may dry out, crack, warp or become discoloured over time. Consult with floor manufacturer for required clearances to a heat source.


Flush Installation

Diagram applies to both combustible and non-combustible finish material.



### **Recessed Installation**

**Diagram applies to both combustible and non-combustible finish material.** The finish must maintain at least a 0.4cm clearance to the fireplace.



### Gas Pressures

Fireplace Series	Burner Size	Burner Type	Gas Type	Inlet Pressures (kPa)		Test Point Pressure	Gas Consumptio n	Orifice Sizes*
				Min Max (kPa)		(kPa)	(Mj/h)	
75	ΛE	Single	Natural Gas	1.13	3.0	0.82	26	650
75	75 45 Sing		Propane	2.75	3.0	1.80	20	220
110	400	2: 1	Natural Gas	1.13	3.0	0.73	37	1200
130	120 100 Single		Propane	2.75	3.0	2.70	30	260
150	150 170 135D Double		Natural Gas	1.13	3.0	0.6	55	1200/1400
170			Propane	2.75	3.0	2.3	50	2x260
200	1005	Double	Natural Gas	1.13	3.0	0.5	52	800/1400
200	160D	Double	Propane	2.75	3.0	1.6	40	2x260

NOTE: It can take up to 20 minutes for the flames to turn yellow.


## Routing the Gas Line

Correctly size and route the gas supply line from the supply regulator to the area where the access panel is located (or to the burner area if no access panel is available), as per the requirements outlined in the latest edition of the National Gas Regulatory in Australia.

The gas and electrical components are attached to the pilot on a flexible gas line and can be kept directly under the fireplace or moved to the side or back of the fireplace within 92 cm of the pilot (located at the centre front of the burner). Gas line should be routed to the access panel area (see "Access Panel" section for details). If no access panel is planned, gas line should be routed to the most accessible area within the 92 cm radius (as shown in diagram below).

A gas shut-off valve and a 30 cm gas flex connector are provided with every fireplace. The location of the gas shut-off valve is dependent on local codes and requirements. Check with your authority having jurisdiction for more information.

WARNING: The main gas valve must be installed to allow complete disconnection of the fireplace from the gas supply piping system for servicing purposes.



Correctly size and route the gas supply line from the supply regulator to the area where the appliance is to be installed.


WARNING –The main gas valve must be installed to allow complete disconnection of the appliance from the gas supply piping system for servicing purposes.

**Control Connections** 

For information on remote and electronic systems, please visit the manufacturer's website: <a href="http://www.mertikmaxitrol.com/">http://www.mertikmaxitrol.com/</a>

# Gas and Electrical Components

Assemblies and components are listed and described in the tables following the figure.



Part Number	Description					
ASB001	Pilot Bracket					
D23	Orifice LPG					
D36	Orifice NG					
G02	Mertik Gas Valve					
G301	Symax Receiver					
G202-XRGB	Symax Wi-Fi Box					
G203-W2ME	Symax Wi-Fi Box Cable					
G07	Thermocouple Block					
G09	Wire Harness for Receiver and Gas Valve					
G10	Switch w. cables 180/500 mm					
G11	Spark Wire					
G12	Pilot Base					
G75	Thermocouple NG					
G14	Thermocouple LPG					

Part Number	Description
ASB002	Pilot Gasket
G13	Electrode Target Type
G121	Main Burner Gas Fitting
G25	Burner Gas Tube
G19	Pilot Gas Tube
G34	Spark Plug Connector
G35	Thermocouple Connector
G36	OLIVE D.4 Pilot gas tube compression ring valve
G37	Pilot gas tube fitting burner side
G38	Pilot Assembly Gasket
G45	Red Cable
G58	Connection fitting 4mm One-piece
G47	Fitting for main line inlet to gas valve GV60

The manufacturer of Ortal's gas and electrical components is Mertik Maxitrol. For information on these components, please visit the manufacturer's website: www.mertikmaxitrol.com

### Gas Conversion

ORTAL fireplaces are closed room sealed systems that can operate with natural gas (NG) or (Universal LPG). The following sections present detailed information about gas routing, pressures, conversion, maintenance and more:

To change the gas source of a fireplace, you need to request a gas conversion kit. Gas conversion can be performed only by technicians who have specific authorization to change these components. The actual change must be done by the authorized technician. Not all installers are authorized to provide gas conversion services.

The following procedure is a guide for NG-LPG conversion.



WARNING: Before starting this procedure, make sure to disconnect the main gas supply to the unit.

Pilot parts NG thermocouple (G75) LPG thermocouple (G14) Burner NG thermocouple connector (G35) Ortal logo Electrode (G13) Receiver and gas valve Spark plug connector Heat gasket Pilot kit Pilot base (G12) Pilot gasket Injector(nozzle) NG(D36),LPG(D23) Pilot and gasket bracket Ring valve (eye) (G36)Orifice gas tube nut (G37)

**NG - LPG Conversion Guide** 

Warning: Before starting this procedure, make sure to disconnect the main gas and high voltage power supply to the unit.

### 1. Remove the front heat barrier and glass.

See the heat barrier and glass removal guide for more details.

#### 2. Remove the burner.

See the burner removal guide for more details.

### 3. Removing the pilot kit:

3a. Remove pilot screws as shown in figure (1).




Figure (1)

- 3b. Pull the pilot down until it it is released from the burner.
- 3c. Pull the receiver and the gas valve out, (as shown in figure (2)).





Figure (2)

Note: See the exploded view in the next page to have a background about the next steps.



3d. Pull the wire to dissconnect it from the receiver, (as shown in figure (3)).




Figure (3)

3e. Remove the nut which is holding the thermocouple pipe, and pull the pipe out, (as shown in figure (4)).




Figure (4)

3f. Remove the nut which is holding the gas pipe, and pull the pipe out, (as shown in figure (5)).




Figure (5)

Note: step (4) explains how to assemble the pilot kit, so if you have a full new kit ignore it and move to step (5).

## 4. Assembling the pilot parts:

- 4a. Assemble the Injector (Nozzle) with the ring valve (Eye) and the gas tube nut then insert them to the gas tube, (as shown in figure (6)).
- 4b. Attach the parts in figure (6) to the pilot base then tight the nut as shown in figure (7).




Figure (6)




Figure (7)

Notice: The LPG nozzle contains a red dot in the hole (.36 mm) ,the NG hole is (.23 mm) and a different shape , (see figure (8)) .




Figure (8)

- 4c. Assemble the Electrode with the spark plug connector and Heat gasket with the wire, (as shown in figure (9)).
- 4d. Use lighter to Dissolve the Heat gasket to reinforce the parts .

Heat gasket

Heat gasket

The wire red side

Ell

The wire red side

Figure (9)

4e. Attach the parts in figure (9) to the pilot base then tight the connector nut, (as shown in figure (10)).




Figure (10)

4e. Assemble the thermocouple pipe, notice that in the NG case, the pipe contains just one connector nut, so you have to insert the second, (as shown in figure (11)).




Figure (11)

4f. Attach the thermocouple pipe to the pilot base then tight the connector nut (as shown in figure (12)).




Figure (12)

5 . Change the base pilot gasket every time you open the pilot base .(See figure (13)).




Figure (13)

6. To change the orifice Use wrench (15) to take out the orifice from the burner as shown if figure (14) .




Figure (14)

# 7. Burner venturi adjustment :

7a. Loosen the venturi nuts, (as shown in figure (15)).




Figure (15)

7b. Adjust the venturi as shown in figure (16), then tight the nuts.

Note: For burners B70, remove the venturi from the burner.




Figure (16)

To reinstall reverse the above procedure.

# Pilot and Thermocouple Maintenance

The pilot flame must be visually checked. The pilot flame has two distinct flames. One engulfs the thermocouple, and the other reaches the main burner. Both flames must be present.

The area around the injector should be inspected. Any foreign material must be removed with a brush or vacuum.




Figure 1: Thermocouple Injector

Always be present when the fireplace is in operation.

### **Thermocouple Maintenance**

Thermocouple integrity and operation must be checked. The installer needs to confirm that the thermocouple is in place, and is not cracked or damaged.

# General Flue Requirements

The fireplace operates using a direct flue system and requires co-axial direct flue pipe. The fireplace must be properly connected to an approved flue system. Flueing is not provided with the fireplace and must be sourced from one of the approved flue manufacturers mentioned in the table below. Proper installation, use, and maintenance of flueing is determined by and can be acquired from the flue manufacturer.

	Flue Requirements											
Fireplace Series	Direct Flue Type	Direct Flue Type Flue Size										
75	Passive Flue (standard)	100/150 co-axial direct flue pipe	DuraVent: Direct Vent Pro									
75	Ortal Power Flue* (optional)	Co-Linear 80mm/80mm										
110	Passive Flue (standard)	130/200 co-axial direct flue pipe	<u>DuraVent: Direct Vent Pro</u>									
120 130	Ortal Power Flue* (optional)	Co-Linear 80mm/80mm										
150	Passive Flue (standard)	130/200 co-axial direct flue pipe	DuraVent: Direct Vent Pro									
170 200 250	Ortal Power Flue* (optional)	Co-Linear 80mm/80mm										

<sup>\*</sup>Power Flue: a fan-assisted direct flue system that boosts airflow for flue configurations with too much constriction. Review "Flue Configurations" section to determine if your fireplace needs a power flue. See the Ortal Power Flue Manual for more details on power flueing.

TERMINATION CAP NOTE: Low Profile Vertical Termination Cap and Sconce Horizontal Termination Cap can negatively impact flame appearance and are not recommended for use with the fireplace.

WARNING: Do not combine flue components from different flue manufacturers. Please follow the manufacturer's instructions for flue system installation.

### Flue Configurations

The following sections provide information for calculating flue configuration distances and elbows. For flue configurations that cannot conform to these guidelines, consider Ortal's Power Flue System, or contact Ortal for assistance. Power Flue information can be found in the Power Flue Installation Manual.

#### Please consider the following guidelines when determining flue configuration:

#### **Elbows**


- Maximum Elbows: Up to four 90° elbows can be used in the flue configuration. Two 45° elbows = one 90° elbows.
  - **45° Vertical Offset Exception:** Two 45° elbows in the <u>vertical plane</u> with a diagonal run in between is equal to **0 elbows**. They are not counted with other elbows in the flue configuration. This offset exception is applicable immediately on the top of the fireplace <u>and</u> anywhere else within the flue configuration.
    - The diagonal run between the two 45° elbows must be included when calculating vertical and horizontal distances.
  - 45° Horizontal Offset: Two 45° elbows that begin and end in the horizontal plane, with a diagonal run in between, is equal to one 90° elbow. Additionally, 1 meter must be reduced from the total allowable horizontal run.
    - The diagonal run between the two 45° elbows must be included when calculating vertical and horizontal distances
- **Exceeding two 90° Elbows:** For more than two 90° elbows, the minimum total vertical rise is **2 metres** for 110-250 models. This does not apply to 75 models.
- **Flat 90° Elbows:** For every flat 90° elbow (a 90° elbow that stays in the horizontal plane), **2 metres** must be reduced from the total allowable horizontal run. Up to two flat elbows are allowed.
  - Example: If max allowable horizontal run is 7 metres and 1 flat elbow is added, max run is reduced to 5 metres.
- 3rd 90° Elbow in the Vertical Plane: The 3<sup>rd</sup> elbow in the <u>vertical plane</u> reduces 1 metre from total allowable horizontal run. Do not include flat elbows when determining which 90° elbow in your configuration is 3<sup>rd</sup> in the vertical plane.
- Exception: If the 3rd 90° elbow in the vertical plane turns the flue direction from horizontal to vertical, the total allowable horizontal run does not require a 3-foot reduction.

#### **Diagonal Runs**

- Calculating Diagonal Runs (D): Diagonal (45°) flue runs have an equal combination of vertical and horizontal aspects. To include diagonal portions of your desired flue configuration when determining overall flue limitations, divide the diagonal distance in half. Add this value to the total vertical rise and total horizontal run distances in your flue configuration. Include these values when utilizing the Flue Configuration Tables below.
  - Example: 2 metres diagonal run = 1 metre vertical rise & 1 metre horizontal run

#### Other

- V Minimum: This is the minimum amount of vertical rise required before the first completely horizontal (not diagonal) run.
- Any flue configuration that does not meet these parameters requires Ortal's review and approval.



TERMINATION CAP NOTE: Low Profile Vertical Termination Cap and Sconce Horizontal Termination Cap can negatively impact flame appearance and are not recommended for use with the fireplace.

### **Allowable Maximum Horizontal Runs**

Series 75								
V minim	V minimum = 0 m							
Vertical (V)	Max Horizontal (H)							
0 m	2 m							
50 cm	4 m							
1 m	9 m							
2 m	11 m							
3 m	11 m							
4 m	11 m							
5 m	9 m							
6 m	9 m							
7 m	8 m							
8 m	7 m							
9 m	6 m							
10 m	6 m							
11 m	4 m							
12 m	0 m							
13 m	0 m							
14 m	0 m							
15 m	0 m							

Series 110-130									
V minimum = 1 m									
Vertical (V)	Max Horizontal (H)								
N/A	N/A								
N/A	N/A								
1 m	8 m								
2 m	11 m								
3 m	11 m								
4 m	11 m								
5 m	11 m								
6 m	11 m								
7 m	11 m								
8 m	11 m								
9 m	11 m								
10 m	11 m								
11 m	11 m								
12 m	6 m								
13 m	0 m								
14 m	0 m								
15 m	0 m								


Series 150-170								
V minimum = 1 m								
Vertical (V)	Max Horizontal (H)							
N/A	N/A							
N/A	N/A							
1 m	8 m							
2 m	12 m							
3 m	12 m							
4 m	12 m							
5 m	12 m							
6 m	12 m							
7 m	12 m							
8 m	12 m							
9 m	12 m							
10 m	11 m							
11 m	11 m							
12 m	6 m							
13 m	0 m							
14 m	0 m							
15 m	0 m							

Series 200								
V minimum = 2 m								
Vertical (V)	Max Horizontal (H)							
N/A	N/A							
N/A	N/A							
N/A	N/A							
2 m	6 m							
3 m	6 m							
4 m	6 m							
5 m	6 m							
6 m	6 m							
7 m	6 m							
8 m	6 m							
9 m	6 m							
10 m	6 m							
11 m	6 m							
12 m	0 m							
13 m	0 m							
14 m	0 m							
15 m	0 m							

Series 250								
V minimum = 2 m								
Vertical (V)	Max Horizontal (H)							
N/A	N/A							
N/A	N/A							
N/A	N/A							
2 m	1 m							
3 m	2 m							
4 m	3 m							
5 m	3 m							
6 m	3 m							
7 m	2 m							
8 m	2 m							
9 m	2 m							
10 m	1 m							
11 m	0 m							
12 m	0 m							
13 m	0 m							
14 m	0 m							
15 m	0 m							

OHART NOTE: Do not include the space elbows take up when calculating your vertical and horizontal distances.

### **Examples using a 110 Front**



### Flue Restrictors

A flue restrictor is a metal plate that reduces the flow of exhaust evacuating the fireplace. A restrictor is only necessary when the flame is receiving too much oxygen. Various-sized restrictors are supplied with every fireplace. See instructions below to determine which restrictor, if any, is recommended for your fireplace.

### **Restrictor Sizing Guidelines**

The restrictor sizing tables in this section determine the recommended restrictor for your flue configuration. These tables show Ortal's recommendations only. The Environment, gas type and other factors may affect the best restrictor choice.

#### How to use the "Recommended Restrictor" tables?

- 1. Find the total vertical rise in your flue configuration along the y-axis.
- 2. Find the horizontal run in your flue configuration along the x-axis.
- 3. Follow the desired rise and run values within the table until they meet. This value is the recommended restrictor size for your flue configuration.

#### ✓ Legend:

- ☑ X: Flue configuration is not allowed. Power flue required.
- **☑ 0**: No restrictor required.
- ✓ Numbers other than 0: Represents the recommended restrictor (by width).

### ☑ Restrictor Sizes:

- 20mm
- 30mm
- 40mm
- 50mm
- 70mm
- 85mmSpace Creator Restrictor Passive Direct Flue
- Space Creator Restrictor Power Flue

NOTE: Space Creator models come with a special restrictor specific to the Space Creator Series. It is not required to use any other available restrictor.

	Restrictor Table: Burner 30-45 – For all models												
V (m)	Value	s in mm											
15	0	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	
14	0	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	
13	0	X	Х	X	Х	Х	X	Х	Х	Х	Х	Х	
12	0	X	Х	X	Х	Х	X	Х	Х	Х	Х	Х	
11	50	50	30	0	0	Х	X	Х	Х	Х	Х	Х	
10	50	50	30	30	30	0	0	Х	Х	X	Х	Х	
9	50	50	30	30	30	0	0	Х	Х	X	Х	Х	
8	50	50	50	30	30	30	0	0	Х	Х	Х	Х	
7	50	50	50	50	30	30	30	0	0	Х	Х	Х	
6	50	50	50	50	30	30	30	30	0	0	Х	Х	
5	50	50	50	50	30	30	30	30	30	0	Х	Х	
4	50	50	50	50	30	30	30	30	30	0	0	0	
3	50	50	50	50	30	30	30	30	30	0	0	0	
2	50	50	50	50	30	30	30	30	30	0	0	0	
1	50	50	50	50	30	30	30	30	0	0	Х	Х	
0.5	0	0	0	0	0	Х	Х	Х	Х	Х	Х	Х	
0	0	0	0	Х	Х	Х	Х	Х	Х	Х	Х	Х	
	0	1	2	3	4	5	6	7	8	9	10	11	H (m)

	Restrictor Table: Burner 100 – For all models except 110HH													
V (m)	Value	alues in mm												
15	0	Х	Х	Х	Х	Х	Х	х	Х	Х	Х	Х	х	
14	0	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	
13	0	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	
12	70	50	50	50	30	30	0	Х	Х	Х	Х	Х	х	
11	70	50	50	50	30	30	30	0	0	0	0	0	Х	
10	70	50	50	50	30	30	30	0	0	0	0	0	Х	
9	70	50	50	50	30	30	30	30	0	0	0	0	Х	
8	70	50	50	50	30	30	30	30	0	0	0	0	Х	
7	70	50	50	50	30	30	30	30	0	0	0	0	Х	
6	70	50	50	50	30	30	30	30	0	0	0	0	Х	
5	70	50	50	50	30	30	30	30	0	0	0	0	Х	
4	70	50	50	50	30	30	30	30	0	0	0	0	Х	
3	70	50	50	50	30	30	30	30	0	0	0	0	Х	
2	70	50	50	30	30	30	30	0	0	0	0	0	Х	
1	50	50	50	30	30	30	0	0	0	Х	Х	Х	х	
	0	1	2	3	4	5	6	7	8	9	10	11	12	H (m)

	Restrictor Table: Burner 135 – For all models except 150HH													
V (m) Values in mm														
15	0	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	х	Х	
14	0	Х	Х	Х	Х	Х	Х	х	Х	х	Х	Х	Х	
13	0	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	
12	70	50	50	50	30	30	0	Х	Х	Х	Х	Х	Х	
11	70	50	50	50	30	30	30	0	0	0	0	0	Х	
10	70	50	50	50	30	30	30	0	0	0	0	0	Х	
9	70	50	50	50	30	30	30	30	0	0	0	0	0	
8	70	50	50	50	30	30	30	30	0	0	0	0	0	
7	70	50	50	50	30	30	30	30	0	0	0	0	0	
6	70	50	50	50	30	30	30	30	0	0	0	0	0	
5	70	50	50	50	30	30	30	30	0	0	0	0	0	
4	70	50	50	50	30	30	30	30	0	0	0	0	0	
3	70	50	50	50	30	30	30	30	0	0	0	0	0	
2	70	50	50	30	30	30	30	0	0	0	0	0	0	
1	50	50	50	30	30	30	0	0	0	Х	Х	Х	Х	
	0	1	2	3	4	5	6	7	8	9	10	11	12	H (m)

Restrictor Table: Burner 160 – For all models except 200HH and 250HH													
V (m)	Value	s in mm	1										
15	0	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	
14	0	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	
13	0	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	
12	0	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	
11	0	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	
10	50	30	30	0	0	0	0	Х	Х	Х	Х	Х	
9	50	30	30	0	0	0	0	Х	Х	Х	Х	Х	
8	50	50	30	30	0	0	0	Х	Х	Х	Х	Х	
7	50	50	30	30	0	0	0	Х	Х	Х	Х	Х	
6	50	50	30	30	0	0	0	Х	Х	Х	Х	Х	
5	50	50	30	30	0	0	0	Х	Х	Х	Х	Х	
4	50	50	30	30	0	0	0	Х	Х	Х	Х	Х	
3	50	50	30	30	0	0	0	Х	Х	Х	Х	Х	
2	30	30	0	0	0	0	0	Х	Х	Х	Х	Х	
1	0	0	2	3	4	5	6	7	8	9	10	11	H (m)

# Flue Clearances

The following clearances apply to the flue system regardless of flue manufacturer.


☑ Flue Clearances						
☑ Sides: 25 mm	☐ Applies to entire circumference when flueing is oriented <b>vertically</b> .					
☑ *Top: 75 mm	☑ Applies to flueing with any amount of <b>horizontal</b> aspect.					
☑ Bottom: 25 mm	☑ Applies to flueing with any amount of <b>horizontal</b> aspect.					


<sup>☑ \*</sup>Exception: Wall thimble top clearance to any material is 25mm.

### Flue Installation and Clearances

When installing the flueing, be sure that the flue pipe is supported by the structural surrounding and not by the firebox. Secure the flue connection to the fireplace with a minimum of 3 self-tapping screws. Each elbow should be strapped to reduce movement or possible disconnection. Follow the instructions of the flue system manufacturer.

### Vertical Clearance Diagram






NOTE: This chart does <u>not</u> apply to a chimney shroud application. See the "Chimney Shroud" section on the following pages for more information.

TERMINATION CAP NOTE: A Low Profile Vertical Termination Cap can negatively impact flame appearance and is not recommended for use with the fireplace.

### **FLUE TERMINATIONS**



а	-	Appliances up to 50 MJ/h input		n)
		Appliances over 50 MJ/h input		
b		From the ground or above a balcony		
С		From a return wall or external corner		
d		From a gas meter (M)		
е	-	From an electricity meter or fuse box (P)	500	
f	-	From a drain or soil pipe	150	
g	-	Horizontally from any building structure (unless appliance approved		
		for closer installation) or obstruction facing a terminal	500	
h	-	From any other flue terminal, cowl, or combustion air intake	500	
i	-	Horizontally from an openable window, door, non-mechanical air		
•		inlet, or any other opening into a building, with the exception of		
		sub-floor ventilation:		
		Appliances up to 150 MJ/h input	500	
		Appliances over 150 MJ/h input	4=00	
k	_	From a mechanical air inlet, including a spa blower		
n	_	Vertically below an openable window, non-mechanical air		
"	_	inlet or any other opening into a building, with the exception of		
		inet or any other opening into a building, with the exception of		

CLEARANCE							
Space Heaters	All other appliances						
Up to 50 MJ/h input	Up to 50 MJ/h input	Over 50 MJ/h input and Up to 150 MJ/h input	Over 50 MJ/h input				
6 in. (150 mm)	20 in. (500 mm)	39 in. (1000 mm)	59 in. (1500 mm)				

- **NOTES:** 1. All distances are measured vertically or horizontally along the wall to a point in line with the nearest part of the terminal.
  - 2. Prohibited area below electricity meter or fuse box extends to ground level.
  - 3. See clause 5.13.6.6 for restrictions on a flue terminal under a roofed area.
  - 4. See Appendix J, Figure J1(a) and J2(a) for clearances required from a flue terminal to a LP Gas cylinder. A flue terminal is considered to be a source of ignition.

MINIMUM CLEARANCES REQUIRED FOR BALANCED FLUE TERMINALS OR THE FLUE TERMINALS OF OUTDOOR APPLIANCES

Flue Terminations

### Flue Maintenance


Regular inspection of the flueing system by an authorized service technician every six months is recommended. The following maintenance routing is recommended:

- 1. Inspect for excessive condensation, e.g., water droplets forming in the inner lining, and subsequently dripping from the joints. This can cause corrosion in the system.
- 2. Check for corrosion in areas exposed to the elements. Components with rust spots or holes must be immediately replaced.
- 3. Ensure that there is no foreign material in the flues. Survey by removing the cap and shining a light down the flue.
- 4. If possible, check all joints and pipes to make sure that nothing has been disturbed or loosened.

# Chimney Shroud


### **Top Open**


Keep a minimum 15 cm clearance around the diameter of the cap's side edge and extending above and below the cap.



### **Sides Open**

Keep a minimum **15 cm** clearance around the diameter of the cap's side edge, and a minimum **25 cm** clearance above the top of the cap. For openings in the shroud, make sure to allow enough airflow space to release the exhaust gases and allow the flue to operate properly.





Covered Alcove: spaces open only on one side and with an overhang

	Horizontal Termination Clearances Continued: Covered Alcove Application							
Lo	cation	Country	Minimum Clearance	Description				
				Clearance under <b>non-vinyl</b> veranda, porch, deck, balcony, or overhang.				
APPLICATION	М		40 cm	NOTE: Termination in a covered alcove space is permitted with the dimensions spec 1. There must be 1-metre minimum between termination caps. 2. All mechanical air intakes within 3 metres of a termination cap must be a minimum metre below the termination cap. 3. All gravity air intakes within 1 metre of a termination cap must be a minimum of 3 below the termination cap.				
	N	A 1 1 / A 1 7	15 cm	Non-vinyl sidewalls.				
ALCOVE	IN	AU/NZ	30 cm	Vinyl sidewalls.				
	Р		20 cm	Alcove height.				
COVERED	Q	See table below.		Alcove width (dependent on number of caps in the space).				
ъ	R		See table below.	Alcove depth (dependent on number of caps in the space).				

# Flue Caps	Q <sub>MINIMUM</sub>	R <sub>MAXIMUM</sub>
1 flue cap	1 metre	2 x Q <sub>ACTUAL</sub>
2 flue caps	2 metres	1 x Q <sub>ACTUAL</sub>
3 flue caps	3 metres	<sup>2</sup> / <sub>3</sub> x Q <sub>ACTUAL</sub>
4 flue caps	4 metres	<sup>1</sup> / <sub>2</sub> x Q <sub>ACTUAL</sub>
	Q <sub>MIN</sub> = # flue caps x 3	$R_{MAX} = (^2/_{# flue caps}) \times Q_{ACTUAL}$

- HORIZONTAL TERMINATION CAP CLERANCES NOTES:
   If exterior walls are finished with vinyl siding, it is <u>required</u> that a vinyl protector kit be installed.
- Flue system termination is not permitted in screened porches.
- Flue system termination is permitted in porch areas with two or more sides open. You must follow all sidewalls, overhang and ground clearances as stated.
- Termination caps may be hot. Consider their proximity to doors or other traffic areas.

TERMINATION CAP NOTE: Sconce Horizontal Termination Cap can negatively affect flame appearance and are not recommended for use with the fireplace.

# Fireplace Heat Barrier

The glass fronts of the fireplace and surrounding surfaces can become extremely hot during and even long after operation. Touching the hot glass front can lead to serious burns. The fireplace heat barrier prevents contact with the glass front.

The heat barrier is constructed to maintain a fixed relationship between essential barrier parts and the outside glass viewing area. The barrier must be installed properly prior to start-up of the firebox.

ORTAL fireplace are fitted with **Double glass** barriers: Barriers made of inner and outer glass.



MARNING – The firebox MUST not be used without the heat barrier in place.

# Removal / Assembly of the Double Glass Heat Barrier and Inner Glass

The procedure below shows how to remove the glass of new design double glass units. To re-install the glass, perform the steps in the opposite order.





Figure 2: Double Glass Heat Barrier: Parts


### To remove the double glass heat barrier:

1. Remove the side trim:

Hold the upper side of the side trim with your index finger, and pull it until it releases from the top magnet.




Continue pulling the side trim until it is disconnected from the bottom magnet.




Repeat with the other side trim.

### 2. Remove the bottom trim:

Lift the end of the bottom trim with your index finger, and pull it up until it releases from the magnets.




Then, pull the bottom trim all the way out.




### 3. Remove the Double Glass holders:

Using a screwdriver, start removing the two screws from each of the front glass holders. Then take them all the way out.




### 4. Remove the double glass:


Using the suction cup, hold the front glass from the centre and raise it until it reaches the top.



Pull the bottom of the glass as shown in the figure:




Pull the glass down, and take it out.



If necessary, repeat the procedure to remove the side glass.


5. Remove the double glass fan covers:

Pull each fan cover up until it is released.



### 6. Remove the front glass brackets:

Using a suction cup, hold the front glass from the centre. While holding the glass, loosen the screws of the upper bracket.




Take all the bottom bracket screws out. Then, remove the bracket.




### 7. Remove the glass:


Pull the suction cup up to lift the glass until it reaches the top.



Pull the suction cup from the bottom until the glass clears the frame.



Pull the suction cup to take the glass all the way out.





If necessary, remove the side glass by repeating Steps 6 and 7.

## Removing/Assembling the Back Panel

The procedure below shows how to remove the back panel of the unit. The procedure is relevant for units that include a reflective panel or granite.

To re-install the panel, perform the steps in the reverse order.





Figure 3: Back Panel: Parts


### To remove the back panel:

- 1. Remove the front glass and the front heat barrier (Fireplace Heat Barrier on page 63)
- 2. Remove the grill screws. Lift the grill and pull it out.




3. Remove the upper panel holders:


Hold the panel, using a suction cup.




Remove the screws from each holder, and take the holders out.




4. Remove the side panel:Lift the panel up, as shown:



Tilt the panel from the bottom, and pull it towards the fireplace centre.




Pull the panel out and remove it.




If necessary, remove the other side panel in the same manner.

### 5. Remove the rear panel:

Remove the bottom holders (if present).



If the screws on the starter collar are type (M10), remove them as shown in the figure below. Do NOT remove Phillips screws from the starter collar.



Remove the rear panel in the same manner as the side panel (see Step 4).

# 75/65 Front Bricks Installation

The following procedure provides guidelines for installing front bricks.




Figure 4: Components for Front Bricks Installation

### To install front bricks:


- 1. Remove the heat barrier and the glass (Fireplace Heat Barrier on page 63).
- 2. Insert the rear brick.




NOTE: The side bricks hold the rear brick.



3. Insert the left and right side bricks.



4. Insert the right and left brick holders, as shown.



### Traditional Bricks Installation

The following procedure provides guidelines for installing traditional bricks.






Figure 5: Components for Traditional Bricks Installation

### To install traditional bricks:


- 1. Remove the heat barrier and the glass (Fireplace Heat Barrier on page 63).
- 2. Insert the rear lower brick.




3. Insert the rear upper brick.



### 4. Insert the side bricks.





5. Insert the brick holders for each side, as shown.



NOTE: The side bricks hold the rear bricks.

6. Push the right and left floor bricks into place, as shown.





### **Electrical Requirements**



WARNING: Disconnect the power supply before servicing any electrical components.

A duplex receptacle with two outlets (not included) must be installed in the location where the gas and electrical components will be placed, which must be to the side or back of the fireplace within **90 cm** of the pilot (see diagram in "Routing the Gas Line" section). Electrical work should be performed by a qualified licensed electrician, per local code.

Outlet Type	Power Requirements
1 Duplex Receptacle (2 outlets)	240V, 15 amp, 60Hz

WARNING: Use of an AC Adapter other than the one provided with the fireplace (manufactured by Mertik Maxitrol) may render the system inoperable.

NOTE: Any device that functions using the same radio frequency as the handset will be affected when remote-controlled handset is in use.

#### **Power Outage**

**Fireplaces with a <u>screen heat barrier</u> and <u>no other optional features</u> (lights, power flue, heat control system, Wi-Fi) may be used with 4 AA batteries in the receiver in addition to the AC Adapter. If the batteries are used instead of the AC Adapter, the fireplace can operate in the event of a power outage to the building. Batteries must be replaced annually.** 

Fireplaces with double glass heat barrier, power flue, or a heat control system may not be used with batteries.

#### Pairing the Remote and Receiver

To set up the remote-control device to operate the fireplace, follow the following guidelines to pair the remote and receiver unit on the same radio frequency.

1. Press and hold the receiver's reset button until you hear two beeps. The first beep is short, and the second beep is long. After the second beep, release the reset button.




- 2. Within the subsequent 20 seconds, press the following button depending on the mode of operation:
  - **10-Button Handset**: Press the button until you see the word "CONN" and a number counting up from 1 to 8 appear on the handset display. This confirms that the synchronization and data exchange are in process.
  - **Puck Handset:** Press and hold the **–** button approximately 4 seconds.
  - Wall Switch: Use the 10-button handset to synch with the receiver. Once the remote and receiver are paired, the
    wall switch will function normally.
- 3. You will hear two short beeps confirming the connection.





- IMPORTANT: For safety/communication purposes, 10-button handset must be located within 8 metres of the receiver.
- If you hear one long beep, this indicates the connection has failed or the wiring is incorrect.
- The connection between remote and receiver only needs to be made once and is not required after changing the batteries in the remote.

# Wiring Diagram

The following diagrams show the electrical wiring required for different feature combinations.







## Home Automation Wiring Diagram

Use the following wiring diagram to connect fireplace control a hardwired home automation system.


#### **Contacts Options/Operation**

**Ignition:** Close contacts 0 (orange) and 2 (brown) simultaneously for 1 second. Fireplace automatically goes to high after ignition.

**Up Flame:** Close contacts 0 (orange) and 1 (red) simultaneously. The contact needs to be closed for 12 seconds to turn the motor from end-stop to end-stop.

**Down Flame:** Close contacts 0 (orange) and 3 (black) simultaneously. The contact needs to be closed for 12 seconds to turn the motor from end-stop to end-stop.

Off: Close contacts 0 (orange) and 3 (black) simultaneously for 1 second.



Wiring Diagram and Operation Sequence

**Mode of Operation:** The external source provides ON and OFF operation only. The Timer/Thermostat handset provides all other functions.

**NOTICE:** The Timer/Thermostat handset in Thermostatic Model controls the room temperature even if the fire is turned on by the external source. If the handset is in Manual Mode, the fire will go to High Fire in the next cycle of external operation.

NOTE: This wiring diagram is for hardwired home automation systems only and will not connect the fireplace to a wireless system.

### Interior Design Media

ORTAL offers logs that are provided with the fireplace unit. This section provides guidelines for safe placement of media.



### WARNINGS –INSTALLING AND HANDLING MEDIA

- DO NOT install the interior design media until appliance installation is complete, the gas line is connected and tested for leaks, and initial burner operation has been inspected and approved.
- ONLY install media provided by the manufacturer or otherwise specifically approved by the manufacturer for installation and operation with the unit.
- The size and position of the media was engineered to give the appliance a safe, reliable and attractive flame pattern. Any attempt to use different media in the fireplace will void the manufacturer's warranty and will result in incomplete combustion, sooting, and poor flame quality.
- Media materials get very hot and will remain hot up to one hour after gas supply is turned off. Handle media only when materials are cool.
- If media are not installed according to the installation instructions, flame impingement and improper combustion could occur and result in soot and/or excessive production of carbon monoxide (CO). Carbon monoxide is a colourless, odourless and toxic gas.
- THIS APPLIANCE MAY EXHIBIT SLIGHT CARBON DEPOSITION

The appliance is NOT designed to burn wood. Any attempt to do so could cause irreparable damage to the appliance and may result in property damage, personal injury and/or loss of life.

Media Placement Guidelines

When installing media, adhere to the following general guidelines:

- Keep the media back from the pilot so at least one burner port is open. Otherwise, there will be delayed ignition.
- Do not use the pilot to support media. This could cause overheating of the thermocouple.
- Keep the media away from the edges and the glass.
- Do not overfill the media tray. Keep 30% of the tray open to allow for airflow.
- When placing stone media, use the space left by the round shape to leave the ports open.
- Do NOT block ports. This will cause delayed ignition.

### Media Placement Guidelines

Follow the tips below for proper log media placement.

• Place the logs carefully to block as few ports as possible.




Figure 6: Burner Log Setup

### **Log Media Placement**

• Logs must be placed in order and preset into location pins as shown:



Figure 7: Log Media Placement for Clear 75 H F/RS/LS/TS/TU/SC, 170 H F/RS/LS/TS/TU



Figure 8: Log Media Placement for Clear 110 H F/RS/LS/TS/TU/SC, 170 H F/RS/LS/TS/TU

• Do not block ports. This will cause delayed ignition.



Figure 9: Log Media Placement for Clear 150 H F/RS/LS/TS/TU/SC, 170 H F/RS/LS/TS/TU



Figure 10: Log Media Placement for Clear 200 H F/RS/LS/TS/TU/SC, Clear 200 F/RS/LS/TS/TU/SC

# Arrangement of pebbles



Pebble arrangement for burner 45




Pebble arrangement for burners 100, 135 and 160

**Do not place pebbles on the burner holes. Arrange pebbles only around the burner holes.** 



Crystal arrangement for burner 45



Crystal arrangement for burners 100, 135 and 160

Do not place crystals on the burner holes. Arrange crystals only around the burner holes.

### Operation



WARNING – Read these instructions carefully before lighting the fireplace.

Four operation options are available for use with the fireplace:

- 10-Button Remote Control Handset (default option, always included with the fireplace)
- Puck Handset (optional accessory)
- Wall Switch (optional accessory)


IMPORTANT: The 10-Button remote control handset is always included with the fireplace regardless of which operation option is chosen. DO NOT DISCARD. The 10-Button remote must be kept within 8 metres of the fireplace at all times.



- Wiring of valve and receiver must be completed before starting ignition. Failure to do so could damage the electronics.
- If operating the fireplace without an AC adapter, battery replacement is recommended at the beginning of each heating season.
- Fireplaces with double glass, power flue, and/or interior lighting features must operate using the AC Adapter and therefore will not operate during a power failure.
- Only the Mertik Maxitrol AC Adapter is permitted for use with the fireplace. Use of other adapter brands can render the system inoperable. The handsets, receivers, wall switches are not interchangeable with other electronics.
- Batteries must be kept within their recommended temperature limits (0°C to 55°C).

### 10-Button Remote Control Handset





© 2019, Maxitrol Company

Control Option	Radio Frequency	Power Supply		
10-Button Handset	918.0 MHz	2 x 1.5V AAA batteries (quality alkaline recommended)	Replace batteries after 2 years or when low battery indicator appears on handset display	
IMPORTANT: For safety/communication purposes, 10-button handset must be located within 8 metres of the receiver.				

NOTE: Any device that functions using the same radio frequency as the handset will be affected when handset is in use.

#### **Operating Instructions**

Instructions for operating the 10-Button Handset are shown below. For more in-depth instructions, please refer to the "Homeowner's Fireplace Operation Manual" or "Remote Operation Instructions".

NOTE: Some options on the remote may not be available for all fireplaces.

#### **Turning the Fireplace On**



- 1. Press the (b) button until you hear continuous beeping, and a blinking series of lines confirms the start sequence has begun; release buttons.
- 2. Main gas flows once pilot ignition is confirmed.
- 3. The system automatically goes into Manual Mode after main burner ignition.

NOTE: When pilot ignition is confirmed, motor turns automatically to maximum flame height.

NOTE: If the Timer function has been set and the fireplace is manually turned on, the Timer function will need to be reset.

### **Turning the Fireplace Off**



1. Press the button to turn the fireplace off.


NOTE: The fireplace may be turned on again after the OFF icon stops flashing.

#### Flame Height Adjustment



- 1. To increase flame height, press and hold the button to desired flame height.
- 2. To decrease flame height, or to set fireplace to pilot flame only, press and hold the 🗡 button.


### Wall Switch



Control Option	Radio Frequency	Power Supply
Wall Switch	N/A	N/A
IMPORTANT: For safety/communication purposes, the 10-button handset must be located within 8 metres of the receiver.		

### **Operating Instructions**


### **Turning the Fireplace On/Off**



**ON:** Press and hold the **ON-OFF** button until two short beeps confirms the start sequence has begun; release button.

**OFF**: Press the **ON-OFF** button.

### Flame Height Adjustment



**INCREASE**: To increase flame height, press and hold (up flame) button.

**DECREASE**: To decrease flame height, press and hold (down flame) button.

Holding the (down flame) button long enough sets the fireplace to pilot flame (Standby Mode).

#### General Maintenance

All servicing, maintenance, interior cleaning and handling of the fireplace, parts and glass must be performed by an authorized Ortal dealer service technician only.

#### Servicing

- Turn off the gas and electricity BEFORE servicing the fireplace.
- It is recommended that a routine inspection is performed at the beginning of each heating season.
- When removing glass from multisided fireplaces, only one side of glass can be removed at a time. Glass must be re-installed before removing glass from a different side.

#### **Burner and Flue Inspections**

- Periodic checks should be made of the burner for correct position and condition. Visually check the flame of the burner, making sure that the flames are steady.
- The flue system must be inspected before use. Annual inspection must be scheduled to ensure the flow of combustion and ventilation air.

#### **Submerged Parts**

Do not use the fireplace if any part has been under water, or if you suspect that it may have been under water. The Ortal dealer service technician must inspect and, if necessary, replace any parts of the control system and any gas controls which have been under water.

#### **Handling the Glass**

Inner glass panel is 5mm ceramic glass. Exterior double glass panel is 5 mm tempered glass. Tempered glass can be sourced locally if replacement becomes necessary. Ceramic glass must be provided by Ortal.

- When removing glass from multisided fireplaces, only one side of glass can be removed at a time. Glass must be re-installed before removing glass from a different side.
- **NEVER** operate the fireplace without the glass properly securely in place.
- The glass must be removed **ONLY** by an authorized Ortal dealer service technician.
- Only an Ortal certified installer is authorized to remove the glass. Glass must be removed using a 20 cm glass-handling suction cup. Lower the glass to rest in a safe place to prevent damage to the glass edges.

#### **Cleaning the Fireplace**

- Only an Ortal dealer service technician can open the fireplace to clean interior surfaces.
- ALWAYS turn off the gas valve before cleaning.
- Do NOT clean when hot. Make sure fireplace has had time to cool prior to cleaning any surface or component, interior or exterior.
- Keep the fireplace clean by brushing and/or vacuuming at least once a year. This can only be performed by an Ortal dealer service technician.
- When removing glass from multisided fireplaces, only one side of glass can be removed at a time. Glass must be re-installed before removing glass from a different side.
- Clean the glass when it starts to look cloudy. Use a damp cloth for cleaning the fireplace and the door.
- Verify correct operation after servicing.

#### **Maintenance Frequency and Equipment Checklist**

- Under normal circumstances, the factory recommendation is to have the fireplace serviced at least once a year. Fireplaces meeting the following conditions should have more frequent service:
  - Fireplaces installed in commercial/public spaces should be serviced every 3 months.
  - Fireplaces installed in climates near the ocean or in other settings where corrosion build-up is more likely should be serviced every 6 months.
- Thermocouple Maintenance:
  - The thermocouple should be replaced annually or as needed in all commercial installations, and in any residential fireplace where the fireplace is operated for an average of 10 hours or more per day.
  - For all other installations, the thermocouple should be replaced every three years or as needed.



## Appendix A: Fireplace Troubleshooting Guide

This appendix provides information and guidelines for troubleshooting, including:

- Pre-troubleshooting Checklist on page 113
- Normal Sequence of Fireplace Operation on page 115
- Troubleshooting Pilot Problems on page 117
- Troubleshooting Thermocouple Problems on page 119
- Troubleshooting Main Burner Problems on page 120
- Troubleshooting Beeping on page 122
- Mertik Maxitrol External Source Operation on page 124



## Pre-troubleshooting Checklist


Before you begin troubleshooting, perform these steps:

- 1. Check the batteries and 6V transformer connection.
- 2. Verify that the switch on the valve is ON.
- 3. Verify that the MANUAL/ON knob on the valve is in the ON position (Figure 11 on page 99).




Figure 11: ON/OFF and Manual Pilot Valve Switches

- 4. Verify that the gas is ON.
- 5. Using the purge port, purge the gas line of air up to the valve (see figure below).







- 6. Using the purge port, check the pressure of inlet/ supply (see figure above). Inlet pressure for NG should be 7 WC
- 7. Verify that the valve and receiver wires are properly connected and tight, and that the interrupter block is tight (hand-tight plus ¼ turn).




Figure 12: Valve/Receiver Wires and Interrupter Block



## Normal Sequence of Fireplace Operation


Turn the fireplace on by pressing the Off/On button.



Figure 13: ORTAL Remote Control

Once the fireplace is turned on, the following sequence of events will occur:

The system checks itself for any trouble. This is accompanied by sequential beeps.
 See the following beeping and fault code table.



- 2. If the initial check is okay, the system initiates spark to the pilot and opens gas to the pilot only.
- 3. Once the pilot is on, the pilot heats up the thermocouple.



- 4. When the thermocouple is heated to the required temperature, it will allow the flow of the millivolt to the valve.
- 5. Once the millivolt is detected by the valve, the valve turns the solenoid for the main burner ON. The fireplace is now fully on.



# Troubleshooting Pilot Problems

The following sections provide step-by-step instructions for troubleshooting issues related to the pilot. If these instructions fail to resolve the problem, please contact ORTAL.



Before beginning, make sure that the glass protective film has been removed.

## Spark But No Pilot

- 1. Review the Pre-troubleshooting Checklist on page 99.
- 2. Review the Normal Sequence of Fireplace Operation on page 101.
- 3. Make sure the inlet line is purged and that no air is present.
- 4. Make sure that the valve is mounted horizontally (unless it is a hanging Console Appliance unit).
- 5. To purge the pilot tube of any air, turn the unit on 5-10 times.
- 6. Verify that all wire connections are tight. Then, check that the interrupter block is screwed in tightly but not too tightly (tightening the interrupter block too much will break it). Refer to Figure 12 on page 100 for details.
- 7. If the problem is not resolved, call ORTAL.

# No Spark to the Pilot

- 1. Review the Pre-troubleshooting Checklist on page 99.
- 2. Review the Normal Sequence of Fireplace Operation on page 101.
- 3. Locate the valve and receiver.
  - a) Once the receiver is located, pull it from the holder.
  - b) Disconnect the wire for the spark wire. Refer to Figure 12 on page 100 for details.
  - Put a small wire on the receiver spark wire port, and place the other side of the wire close to the metal body without touching (about 3mm) While watching the small wire, turn the unit on and see if there is a spark jumping from the wire to the body of the fireplace. If there is, proceed to the next step. If there is not, call ORTAL.
- Remove the heat barrier and the glass. For instructions, refer to Fireplace Heat Barrier on page 63.
- Remove the grill and the burner. For instructions, refer to Error! Reference source not found. on page Error! Bookmark not defined..
- 6. Remove the pilot assembly from the burner.
- Reconnect the spark wire and disconnect the wire from the spark plug. Place the spark wire close to the metal body of the fireplace without touching (about 3mm). If there is no spark or a weak spark jumping from the wire, replace the wire. If the spark is strong and jumping, proceed to the next step.
- 8. If the problem is not resolved, replace the spark plug. Call ORTAL if a spark plug is needed.

Pilot Turns Off After Igniting But Before Burner Turns On

1. Replace the battery.



- 2. Review the Normal Sequence of Fireplace Operation on page 101.
- 3. Turn the unit on, and listen and look at the pilot section. Once the pilot is on, is the spark continuing to ignite the pilot? If it is, go to Troubleshooting Thermocouple Problems on page 105. If it is not, proceed to the next step.
- 4. Remove the heat barrier and the glass. For instructions, refer to Fireplace Heat Barrier on page 63.
- 5. Make sure the pilot assembly and the pilot hood screw are tight and that there is a gasket. Whenever the pilot assembly is disturbed, replace the gasket.
- 6. If the problem is not resolved, call ORTAL.

# Pilot Turns Off After Igniting and After Burner Turns On

- 1. Review the Normal Sequence of Fireplace Operation on page 101.
- 2. Remove the heat barrier and the glass. For instructions, refer to Fireplace Heat Barrier on page 63.
- 3. Make sure that the valve is mounted horizontally (unless it is a hanging Console Appliance unit).
- 4. Turn the unit on and see if the pilot is still turning off after the burner turns on. If it turns off, make sure the flame from the pilot is hitting the thermocouple.
- 5. Verify that the pilot assembly and pilot hood screw are tight, and that the pilot assembly gasket is present and in good condition.
- 6. Review the restrictor tables and check that the correct restrictor is in place.
- 7. If the problem is not resolved, call ORTAL.



# Troubleshooting Thermocouple Problems

The following sections explain how to check and test the thermocouple.

Checking the Thermocouple

Perform these steps to check the thermocouple. Refer to Figure 12 on page 100 for details.

- 1. Place new batteries in the receiver.
- 2. Check for any breakage to the thermocouple from pilot assembly to the valve.
- 3. Check that the thermocouple is tightly connected to the interrupter block and that the thermos current cable is securely touching the end of the thermocouple.
- 4. Verify that the interrupter block is screwed into the valve properly and is finger-tight, plus ¼ turn.
- 5. Verify that the thermo current cable TC is screwed into the receiver properly and is tight.
- 6. Verify that the thermo current cable SW is screwed into the receiver properly and is tight.
- 7. Verify that the thermo current cable SW is securely placed in the interrupter block.

# Testing the Thermocouple

Perform these steps to test the thermocouple. Do not begin testing until the thermocouple check has been completed.

- 1. Remove the heat barrier and the glass. For instructions, refer to Fireplace Heat Barrier on page 63.
- 2. Turn off gas to the unit.
- 3. Turn the unit on. While the spark is sparking, place a heat source to the thermocouple. Sparking should stop once the thermocouple senses that there is heat. If the spark does not stop, go to Step 5.
- 4. Check that the thermocouple is screwed properly into the interrupter block. Verify that the thermo current cable is screwed in tightly at the receiver, and that the other end is touching the head of the thermocouple at the interrupter block.
- 5. If the problem is not resolved, the thermocouple should be replaced. Complete a part claim/replacement form and call ORTAL for replacement.



# Troubleshooting Main Burner Problems

The tables below provide instructions for troubleshooting issues related to the main burner and the flame.

Problem	Possible Causes	Recommended Actions	
Main burner does not turn on. Pilot is on, and valve on sequence is done.	Manual pilot valve operation is off.	Verify that the manual pilot valve operation is in the ON position.	
Main burner turns off after a period of time.	<ul> <li>Thermostat is set too low.</li> <li>There is a problem with the flame.</li> </ul>	Check whether the pilot stays on when the main burner turns off.  • If the pilot stays on, make sure the remote thermostat is set to the desired temperature or to the highest temperature allowed on the remote, so the system does not turn the burner off.  • If the pilot does not stay on, check the appearance of the flame before the fireplace turns off. Refer to Troubleshooting Flame Issues on page 107.	
Main burner is turning on and off.	The pilot flame is being intermittently deflected off the thermocouple.	Make sure the pilot assembly screw is tight and that the gasket is present and in good condition.	



# Troubleshooting Flame Issues

Problem	Possible Causes	Recommended Actions	
There is a faint or blue flame.	<ul> <li>Too much CO in the fireplace, due to CO back feeding or an unapproved flue run.</li> </ul>	<ul> <li>Review the flue run. If the size of the restrict in the unit is incorrect, replace it with the correct size. If it is the right restrictor, check the pipe for proper connections and for termination blockage.</li> </ul>	
	• Too much O2 in the fireplace.	<ul> <li>Review the flue run. If the size of the restrictor in the unit is incorrect, replace it with the correct size. If it is the right restrictor, replace it with a bigger one.</li> </ul>	
The flame is jumping from the burner.	Too much draw in the fireplace.	Review the flue run. If the size of the restrictor in the unit is incorrect, replace it with the correct size. If it is the right restrictor, replace it with a bigger one.	
Part of the burner is not turning on.	<ul> <li>Too much CO in the fireplace, due to CO back feeding or an unapproved flue run.</li> <li>Too much media.</li> <li>Burner ports are clogged.</li> </ul>	<ul> <li>Review the flue run. If the size of the restrictor in the unit is incorrect, replace it with the correct size. If it is the right restrictor, check the pipe for proper connection.</li> <li>Remove some of the media. No more than 70% of the burner and grill surface area should be covered.</li> <li>Check burner ports for blockage.</li> </ul>	
The flame is small.	Unit manifold pressure is incorrect.	Set the correct pressure.	



# Troubleshooting Beeping

# **BEEPS 2008 ELECTRONIC**

CONFIRMATION OF A VALID SIGNAL also Reset, new Batteries	
FAILURE: Microswitch defect ON-OFF Switch open WIRING NOT COMPLETED LEARN FUNCTION FAILED	
LOW BATTERY (During the motor turns)	
SYMBOL FOR IGNITION SEQUENCE	
LEARNING FUNCTION	PUSH RESET PUSH SMALL FLAME



## **BEEPS 2010 ELECTRONIC**

CONFIRMATION OF A VALID SIGNAL also Reset, new Batteries				
FAILURE: Micro switch defect ON-OFF Switch open WIRING NOT COMPLETED LEARN FUNCTION FAILED				
LOW BATTERY (During the motor turns)				
SYMBOL FOR IGNITION SEQUENCE				
	CONFIRMS CODE LEARNING			
LEARNING FUNCTION	PUSH RESET PUSH SMALL FLAME			



# **BEEPS 2013 ELECTRONIC (B6R...)**





# Mertik Maxitrol External Source Operation

The following figure is taken from the Mertik Maxitrol guide.

# **MERTIK MAXITROL**

# gV60 Remote electronic ignition and Control system external source operation



### **Contact Options/Operation**

#### **WARNING**

Fire or explosion hazard. Attempted disassembly or re-pair of controls can cause property damage, severe injury or death. Do not disassemble the gas valve; it contains no serviceable components.

Read these instructions carefully and completely before installing or operating. Failure to follow them could result in a fire or explosion causing property damage, personal injury, or loss of life. Service and installation must be performed by a trained/ experienced service technician. The Mertik Maxitrol product should not be operated until it has been inspected and approved by the local code authority.

#### What to do if you smell gas:

- Do not operate any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately evacuate the area and contact the gas supplier. Follow the gas supplier's instructions.
- If you cannot reach the gas supplier, call the fire department.

Do NOT use this product if you suspect it has been subjected to high temperatures, damaged, tampered with, or taken apart.

Do NOT use a product if you suspect it has been under water or that liquid has seeped into the product. Any of these incidents can cause leakage or other damage that may affect proper operation and cause potentially dangerous combustion problems.

Do not store or use gasoline or other flammable vapors and liquids near this control or other appliances.

Use only your hand to push in or turn the gas control knobs. Never use tools. If a knob will not push in or turn by hand, do NOT try to repair it. Call a qualified service technician. Force or attempted repair can result in a fire or explosion.

#### Description

The GV60 will operate through an external source, such as a home automation system, by using the 5-wire pin connector on the receiver. A 1000 mm cable with Alex 2510-Z connector (part number G60-ZCE/1000) is available. The overall length of the cable should not exceed 8 m. Signal relays (gold contacts) or opto-couplers are recommended.

#### **WARNING**

It is the appliance manufacturer's responsibility to fully disclose any operation from a remote source that will create an unsafe operating condition. For Europe see GADAC guidance sheet

# FOR OEM USE ONLY

## **Contacts Options/Operation**

- Ignition: Close contact 1 and 3 simultaneously for 1 second.
- Fireplace automatically goes to high after ignition sequence.
- **UP FLAME:** Close contact 1. The contact needs to be closed for 12 seconds to turn the motor from end-stop to end-stop.
- DOWN FLAME: Close contact 3. The contact needs to be closed for 12 seconds to turn the motor from end-stop to end-stop.
- Off: Close contacts 1, 2, and 3 simultaneously for 1 second.




Figure 1: Wiring diagram and the operation sequence

#### Possible modes of Operation

#### Mode 1

The external source provides ON and OFF operation only. The Timer/Thermostat handset provides all other functions.

#### NOTICE

The Timer/Thermostat handset in Thermostatic Mode controls the room temperature even if the fire is turned on by the external source. If the handset is in Manual Mode, the fire will go to High Fire in the next cycle of external operation.

#### Mode 2

The external source controls the room temperature. The Timer/Thermostat handset must be set to Manual Mode (or use a standard handset). If the Timer/Thermostat handset is set to Thermostatic Mode, it will override the external source.

#### NOTICE

Frequent ON/OFF cycles will limit the life expectancy of the valve and will increase the battery consumption. The AC Mains Adapter may be used instead of batteries.

# **MERTIK MAXITROL**



Append	x E: ORTAL Factory Recommended Service Checklist
Model Type	:Serial #:Date:
Before, duri	ng and after service, if there is any doubt, stop and call ORTAL.
	If there is any NO answer, close the gas valve and correct.  If you cannot correct, discontinue operation, lockout unit and call ORTAL.
1.	Outside horizontal/vertical cap. Clean and unobstructed. ( ) Yes ( ) No
2.	Check the louver/Cavity heat release. Clean and unobstructed. ( ) Yes ( ) No
3.	Is there an access panel for valve and receiver maintenance? ( ) Yes ( ) No a) Clean and unobstructed? ( ) Yes ( ) No b) Allows access to components? ( ) Yes ( ) No
4.	LPG only: Is there adequate opening for releasing a potential gas leak at the lowest point of elevation in the Cavity? ( ) Yes ( ) No
5.	Is glass complete and NOT broken? ( ) Yes ( ) No
6.	Is area around the fireplace free of wall crack or signs of heat impact? ( ) Yes ( ) No Make sure the shut-off valve is in the ON position and there is gas flow. ( ) Yes ( ) No
7.	Verify that there is NO gas leak. ( ) Yes ( ) No
8.	Turn on the fireplace for visual inspection (30 sec- 1 minute).  a) Check if the system sparks. () Yes () No  b) Check if the pilot turns on. () Yes () No  c) Check if the burner turns on. () Yes () No  d) Measure gas pressure. InletkPA. ManifoldkPA.
9.	Let the glass cool down.
10.	Remove glass. a) Clean the glass. b) Remove the media and clean / vacuum the burner. ( ) Yes ( ) No c) Return media per installation guidelines. ( ) Yes ( ) No d) Make sure pilot, spark plug and thermocouple area is clear. ( ) Yes ( ) No
11.	Check explosion valve  a) Push explosion valve open.  b) Release explosion valve to close. Is the explosion valve closed? ( ) Yes ( ) No  c) Is the explosion valve unobstructed? ( ) Yes ( ) No
12.	Turn unit on without the glass installed to verify the following:  Block the flame from the pilot to the thermocouple with a metal or similar divider, and verify that the main burner turns off. () Yes () No
13.	Reinstall the glass.
14.	Check silicon on the glass. If broken, flip glass to the other edge. If the other edge is also broken, apply new silicon and cure for 24 hours.  Tell owner not to turn unit on for 24 hours, until: Date:  Time



# **ORTAL Product Service Log**

Product Name/ Model Type:
Product Name/ Model Type:Date of Service:
Location Information Name:
Address:
City, State, Zip:
Is this unit installed in a Commercial/Public space or Residential?
Service call: () Routine or () special request. If requested, why?
Service Technician Installation Technician Name:
NFI Gas Specialist ID #:
Technician Company Name:
Technician Signature and date:
Customer Company Name:
Fireplace Customer/Owner
Customer Individual Name:
Customer Signature and date:

A copy of this service record to remain with the fireplace unit and Owner. A copy of this service record to remain with the service technician.

If any product or warranty concerns are present or replacement parts are required please provide a copy of the complete service record to:

ORTAL HEATING SOLUTIONS LTD.
SERVICE DEPT.
14 HAHARASH ST.
HOD HASHARON, ISRAEL
FAX: +972-9-7402687

e-mail: qa@ortal-heat.com



# Appendix F: Warranty Policy

Below is the warranty policy of Ortal Ltd for Standard products sold and distributed in Australia & New Zealand. Warranties may vary for custom models.

#### THE WARRANTY

The Ortal Ltd. Limited Warranty warrants your Ortal gas fireplace ("Product") to be free from defects in materials and workmanship at the time of manufacture. The Product body and firebox carry the 10 Year Limited Warranty. Ceramic glass carries the 2 Year Limited Warranty against thermal breakage only. After installation, if covered components manufactured by Ortal are found to be defective in materials or workmanship during the Limited Warranty period and while the Product remains at the site of the original installation, Ortal will, at its option, repair or replace the covered components. If repair or replacement is not commercially practical, Ortal will, at its option, refund the purchase price or wholesale price of the Ortal product, whichever is applicable. Ortal will also pay Ortal prevailing labour rates, as determined in its sole discretion, incurred in repairing or replacing such components for up to 2 years. There are exclusions and limitations to this limited warranty as described herein.

# **COVERAGE COMMENCEMENT DATE**

Warranty coverage begins on the date that the fireplace shipped from Oblica's warehouse.

#### **EXCLUSIONS AND LIMITATIONS**

This Limited Warranty applies only if the Product is installed in the Australia and/or New Zealand and only if installed, operated and maintained in accordance with the printed instructions accompanying the Product and in compliance with all applicable installation and building codes and good trade practices. Printed instructions include those, which direct the installer and/or owner to refer to the product information, diagrams, and operation and maintenance manuals available on Ortal's website, www.ortalheat.com. These can also be requested in digital format direct from Ortal's office(s).

This warranty is non-transferable and extends to the original owner only. The Product must be purchased through a listed supplier of Ortal and proof of purchase must be provided. The Product body and firebox carry the 10 Year Limited Warranty from the date of installation. Flue components, trim components and paint are excluded from this Limited Warranty. The following components are part of the Limited Warranty and are warranted as follows:

□ Burner: Repair or replacement - two years coverage.	
☐ Gas Components (including the valve): Repair or replacement - two years.	
$\ \square$ <b>Interior Decorative Media:</b> Replacement for one year from the date of installation againthermal breakage only	inst
<ul> <li>Electrical components and Remote Controls: Repair or replacement - two years. We damage and batteries are entirely excluded.</li> </ul>	ater
□ Ceramic Glass: Replacement for two years against thermal breakage only.	
<ul> <li>Labour Coverage: Prevailing Ortal labour rates apply for the warranty period of complete Labour coverage is for actual repair and/or replacement of components. Troubleshooting excluded.</li> </ul>	



Parts not otherwise listed carry a 90-day warranty from the date of installation.

Whenever practicable, Ortal will provide replacement parts, if available, for a period of 2 years from the last date of manufacture of the Product.

Ortal will not be responsible for: (a) damages caused by normal wear and tear, accident, riot, fire, flood, climate and weather corrosion or natural disaster; (b) damages caused by abuse, negligence, misuse, or unauthorized alternation or repair of the Product affecting its stability or performance. The Product must be subjected to normal use. The Product is designed to burn on either natural or propane gas only as determined by the costumer when originally purchased or changed after installation by an authorized installer only. Burning conventional fuels such as wood, coal or any other solid fuel will cause damage to the Product, will produce excessive temperatures and could result in a fire hazard.; (c) damages caused by failing to provide proper maintenance and service in accordance with the instructions provided with the Product; (d) damages, repairs or inefficiency resulting from faulty installation or application of the Product.

Ortal is not responsible for inadequate fireplace system draft caused by air conditioning and heating systems, mechanical ventilation systems, or general construction conditions which may generate negative pressure in the room in which the appliance is installed. Additionally, Ortal assumes no responsibility for drafting conditions caused by flueing configurations, adjoining trees or buildings, adverse wind conditions or unusual environmental factors and conditions that affect the operation of the unit.

This Limited Warranty covers only parts and labour as provided herein. In no case shall Ortal be responsible for materials, components or construction, which are not manufactured or supplied by Ortal or for the labour necessary to install, repair or remove such materials, components or construction. Additional utility bills incurred due to any malfunction or defect in equipment are not covered by this warranty. All replacement or repair components will be shipped F.O.B. from the nearest stocking Ortal warehouse.

# LIMITATION ON LIABILITY

It is expressly agreed and understood that Ortal's sole obligation and the purchaser's exclusive remedy under this warranty, under any other warranty, expressed or implied, or in contract, tort or otherwise, shall be limited to replacement, repair, or refund, as specified herein.

In no event shall Ortal be liable for any incidental or consequential damages caused by defects in the Product, whether such damage occurs or is discovered before or after repair or replacement, and whether such damage is caused by Ortal's negligence. Ortal has not made and does not make any representation or warranty of fitness for a particular use or purpose, and there is no implied condition of fitness for a particular use or purpose.

Ortal makes no expressed warranties except as stated in the Limited Warranty. The duration of any implied warranty is limited to the duration of this expressed warranty. No one is authorized to change this Limited Warranty or to create for Ortal any other obligation or liability in connection with the Product. Some states and provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. The provisions of the Limited Warranty are in addition to and not a modification of or subtraction from any statutory warranties and other rights and remedies provided by law.



# **INVESTIGATION OF CLAIMS AGAINST WARRANTY**

Ortal reserves the right to investigate any and all claims against this Limited Warranty and to decide, in its sole discretion, upon the method of settlement.

To receive the benefits and advantages described in this Limited Warranty, the appliance must be installed and repaired by either a qualified or authorized Ortal installation technician. Refer to your dealer/distributor sales agreement for requirements. Contact Ortal at the address provided herein to obtain a listing of approved dealers/distributors and certified/authorized installer companies.

Ortal shall in no event be responsible for any warranty work done by an installer that is not approved without first obtaining Ortal's prior written consent.

## **HOW TO REGISTER A CLAIM AGAINST WARRANTY?**

In order for any claim under this warranty to be valid, you must contact the Ortal dealer/distributor from which you purchased the product. If you cannot locate the dealer/distributor, then you must notify Ortal in writing. Submission of a completed warranty claim is the preferred method of warranty claim notification. Ortal must be notified of the claimed defect in writing within 90 days of the date of failure. Notices should be directed to the Ortal Warranty Department or visit our website at www.ortalheat.com/

Printed in Israel. © 2024 Ortal Ltd.



# Manufacturer Contact Information

For all service issues, please contact your local dealer.

ORTAL HEATING SOLUTIONS LTD.
SERVICE DEPT.
14 HAHARASH ST.
HOD HASHARON, ISRAEL
FAX: +972-9-7402687

e-mail: qa@ortal-heat.com

Installer			
Company N	ame: _		_
Technician	Name:		_
Address: _			
			_
			_
Te1:			_
Fax:			_
E-mail: _			
Website: _			



© Ortal 2024

Ver. 1.0 June 2024 KPMANNLAUV1.0